

PRODUCT MANUAL

CPS3200U


Technical Support Guide

Product Manual

Ordering code CC848853457

This page intentionally left blank.

CPS3200U Technical Support Guide



Home Reports Maintenance Settings Installation

FTTN System Overview

Groups				Circuits															
Description	Circuits	Current	Capacity	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
FTTN DEFAULT GROUP	20	12mA	5140mA	382	381	380	379	379	380	382	382	381	381	n/a	n/a	n/a	n/a	n/a	n/a
FTTN GROUP 001	0	0mA	0mA	1	1	1	1	1	0	1	1	1	1	n/a	n/a	n/a	n/a	n/a	n/a
FTTN GROUP 002	0	0mA	0mA																
FTTN GROUP 004	0	0mA	0mA																
FTTN GROUP 005	0	0mA	0mA																

SH01 1.5 A
A 1-8 9-16 CB
B 1-8 9-16 CB
upper fan
lower fan



WEB

Front Panel

This document is a compilation of class material aimed at people who provide technical support. Information pulled from product manuals is marked with a reference indicator in brackets.


CPS3200U

Technical Support Guide

Table of Contents

1. Hardware	5
Brief Hardware Orientation	6
Always look first at the alarm card to establish valid A and B power feeds to both sides of the shelf	7
This diagram can be used to diagnose powering faults as indicated by the “A” and “B” LEDs	7
Once both the “A” and the “B” input power LEDs are green, other LEDs can be used to diagnose other faults.....	8
The Shelf ID rotary DIP switches are as shown here:.....	8
Converter LEDs look like this:.....	9
Alarm Reference Table	10
Locating Failed Fans	12
2. WEB	13
The web page reflects the physical configuration of each shelf.....	14
To help find the FTTN relevant information on each tab, please use this guide	14
To interact with the QS941 Controller through the WEB interface it is possible to connect a computer to the QS941A directly using server mode or through a LAN using client mode	16
3. Front Panel	19
Most of the detail needed to interact with the front panel is in the QS941A Controller User Interface document available from the OmniOn website	20

1. Hardware



Groups				Circuits															
Description	Circuits	Current	Capacity	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
FTTN DEFAULT GROUP	20	12mA	5140mA	382	381	380	379	379	380	382	382	381	381	n/a	n/a	n/a	n/a	n/a	n/a
FTTN GROUP 001	0	0mA	0mA	1	1	1	1	1	0	1	1	1	1	n/a	n/a	n/a	n/a	n/a	n/a
FTTN GROUP 002	0	0mA	0mA																
FTTN GROUP 004	0	0mA	0mA																
FTTN GROUP 005	0	0mA	0mA																

a V SH01 1.5 A
 A 1-8 9-16 CB
 B 1-8 9-16 CB
 upper fan
 lower fan

WEB



Front Panel

Brief Hardware Orientation




Figure 6-1: QS912A Converter Shelf
(Shown configured with 2 operational circuits and 14 slot fillers for airflow control)

[CPS3200U Page 21]

To distribute airflow across every card in the shelf make sure each slot is filled with either a converter or an empty slot filler. Converter cards and slot fillers are inserted according to this diagram:





Figure 8-2: Installing Converters

[CPS3200U Page 40]

Please shift focus now to understanding the shelf schematic. This is key to recognizing and correcting errors.

Always look first at the alarm card to establish valid A and B power feeds to both sides of the shelf.



[CPS3200U Page 7]

The orange and blue regions above indicates that there is an A and a B feed for the left hand side of the shelf (slots 1-8) and an A and a B feed for the right hand side of the shelf (slots 9-16). The letters “A” and “B” labeling the top two alarm card LEDs refer to these -48V input power feeds.

This diagram can be used to diagnose powering faults as indicated by the “A” and “B” LEDs.

[CPS3200U Page 55]


Energized (E) is the normal state. This makes any failures of power to the relay are alarmed:

	-48 V INPUT BUS				Vin LEDs		STATUS LEDs		ALARM RELAYS	
	A1-8	B1-8	A9-16	B9-16	A LED	B LED	OK LED	ALMLED	PMN	PMJ
1	OK	OK	OK	OK	GRN	GRN	GRN	OFF	E	E
2	LOW	OK	OK	OK	RED	GRN	OFF	YEL	D	E
3	OK	LOW	OK	OK	GRN	RED	OFF	YEL	D	E
4	OK	OK	LOW	OK	RED	GRN	OFF	YEL	D	E
5	OK	OK	OK	LOW	GRN	RED	OFF	YEL	D	E
6	LOW	LOW	OK	OK	RED	RED	OFF	RED	E	D
7	LOW	OK	LOW	OK	RED	GRN	OFF	RED	E	D
8	LOW	OK	OK	LOW	RED	RED	OFF	RED	E	D
9	OK	LOW	LOW	OK	RED	RED	OFF	RED	E	D
10	OK	LOW	OK	LOW	GRN	RED	OFF	RED	E	D
11	OK	OK	LOW	LOW	RED	RED	OFF	RED	E	D
12	LOW	LOW	LOW	OK	RED	RED	OFF	RED	E	D
13	LOW	LOW	OK	LOW	RED	RED	OFF	RED	E	D
14	LOW	OK	LOW	LOW	RED	RED	OFF	RED	E	D
15	OK	LOW	LOW	LOW	RED	RED	OFF	RED	E	D
16	LOW	LOW	LOW	LOW	OFF	OFF	OFF	OFF	D	D


Alarm Relay: E – Energized relay in non-alarm state; D – De-energized relay in alarm state

Once both the “A” and the “B” input power LEDs are green, other LEDs can be used to diagnose other faults.

One fault that may show as a red flashing ALM LED on the alarm card is communications fail. The flashing red ALM light on the alarm card indicates that it is configured to expect a controller and is not seeing one.



The Shelf ID rotary DIP switches are as shown here:











[CPS3200U Page 53]

If there is no controller present, the flashing red LED can be addressed by switching the Tens and Units rotary switches to positions 0 using a small Phillips screwdriver. If a controller is present the signal between the alarm card and the controller is likely broken. Please examine all wiring. Also note: all shelves in a system must have different addresses to be recognized by the controller.

Converter LEDs look like this:

[CPS3200U Page 52]

LED Display	Conditions (on b circuit)	Action Required
 <p>a OK b Green FLT Off</p>	All OK	None
 <p>a Off b Yellow FLT Off</p>	Circuit Placed in Standby	None depending on desired state of circuit b. Standby state can be set using the QS941 controller or web browser.
 <p>a Green b Green FLT Red Blinking</p>	Loss of comm.	Check seating on Alarm card and converter card
 <p>a Red Blinking b Red Blinking FLT Red Blinking</p>	Ground fault	Check 5 pin protectors and faults to ground
 <p>a Green b Yellow Blinking FLT Off</p>	Overcurrent or undervoltage	Check output lines for shorts to each other
 <p>a Red Blinking b Off FLT Off</p>	OV or internal failure	Replace unit
 <p>a Off b Red Blinking FLT Off</p>	Thermal Alarm	Solve Thermal problem
 <p>a Off b Off FLT Off</p>	card not powered or input fuse failure	Check source voltage

Converter LEDs look like this:

[CPS3200U Page 52]

LED Display	Conditions (on b circuit)	Action Required
	Lamps test requested from controller	Observe Lamp Test

Alarm Reference Table

This Alarm Table shows how FTTN Alarms are categorized by the QS941 Controller. Many alarms are best processed at the converter shelf alarm card and converter card level. In other words columns 4, and 5, can be used to select the appropriate action from column 6.


		3. QS941		4. Alarm Card		5. Converter Card		6. Human Response
1. Alarm Display	2. What it means	LED State	Relay State	Alarm LED State	Relay State	OK LED State	Alarm LED State	Corrective Action
Circuit Fail	Short + to -	Yellow	Min	Yellow	Min	Green	Flashing Yellow	Make sure each converter has an independent isolated send and return path.
Circuit Fail	Short to Ground	Yellow	Min	Yellow	Min	Flashing Red	Flashing Red	Make sure each converter has an independent isolated send and return path.
Comm. Fail	1 Card Removed	Yellow	Min	Yellow	Min	Green	Off	Check to see that all cards are seated. Replace non- functioning cards.
Comm. Fail	2 Cards Removed	Red	Maj					Check to see that all cards are seated. Replace non- functioning cards.
Comm. Fail	Comm. Cable Removed	Red	Maj	Flashing Red		Green	Off	Check communication path from alarm cards to QS941 controller. If no controller is present, set alarm card rotary switch to position 0 for contact closures only communication.
Comm. Fail	Alarm Card Removed	Red	Maj			Green	Flashing Red	Replace Alarm card.
None	Standby	Green		Green			Yellow	Remove unit from standby if desired using QS941 or Ethernet interface

		3. QS941		4. Alarm Card		5. Converter Card		6. Human Response
1. Alarm Display	2. What it means	LED State	Relay State	Alarm LED State	Relay State	OK LED State	Alarm LED State	Corrective Action
Circuit Fail	Open Fuse	Yellow	Min	Yellow	Min	Green	Flashing Yellow	Replace unit. Note: Restoring service to one line will interrupt service to the other line served by that card.
Circuit Fail	Under Voltage	Yellow	Min	Yellow	Min		Flashing Yellow	Replace unit. Note: Restoring service to one line will interrupt service to the other line served by that card.
Fan Fail	1 Fan Tray Failed	Yellow	Min	Yellow	Min	Green	Off	Replace fan tray.
Fan Fail	1 of 6 fans Failed on one Fan Tray	Yellow	Min	Yellow	Min	Green	Off	Replace fan tray.
Fan Fail	2 Fan Trays Failed	Red	Maj	Red	Maj	Green	Off	Replace fan trays.
Input Power	A1-8 Power Fail	Yellow	Min	A Red	Min	Green	Off	Reconnect DC input power flowing to the A1-8 input terminal.
Input Power	B1-8 Power Fail	Yellow	Min	B Red	Min	Green	Off	Reconnect DC input power flowing to the B1-8 input terminal
Input Power	A9-16 Power Fail	Yellow	Min	A Red	Min	Green	Off	Reconnect DC input power flowing to the A9-16 input terminal
Input Power	B9-16 Power Fail	Yellow	Min	B Red	Min	Green	Off	Reconnect DC input power flowing to the B9-16 input terminal.
Input Power Mul Circuit Fail	A1-8 & B1-8 Power Fail	Red	Maj	A Red B Red	Maj	Green	Off	Reconnect DC input power flowing to the A1-8 input terminal and Reconnect DC input power flowing to the B1-8 input terminal
Input Power Mul Circuit Fail	A9-16 & B9-16 Power Fail	Red	Maj	A Red B Red	Maj	Green	Off	Reconnect DC input power flowing to the A9-16 input terminal. Reconnect DC input power flowing to the B9-16 input terminal.


		3. QS941		4. Alarm Card		5. Converter Card		6. Human Response
1. Alarm Display	2. What it means	LED State	Relay State	Alarm LED State	Relay State	OK LED State	Alarm LED State	Corrective Action
Load Drop	Load Drop	Yellow	Min	A, B & OK Green		Green	Off	Check the integrity of the circuits going to the load. Or Adjust load drop threshold to 0 to disable this feature.
Load Share	As set of circuits assigned to one remote destination are not sharing current as would be expected.	Yellow	Min	A, B & OK Green		Green	Off	Check the integrity of the circuits going to the load. Or Adjust load share threshold to disable this feature.
Line Test	OK, Fail or Aborted			A, B & OK Green		Green	Off	Estimated line resistance has increased since last measurement.
Loss Of Redundancy		Yellow	Min	A, B & OK Green		Green	Off	The loss of n additional circuits will cause customer to lose service. Check redundancy threshold in the configuration.

Locating Failed Fans

Fan failures within a tray can be found by correlating the number of LED flashes to this map:



2. WEB



Hardware

Home Reports Maintenance Settings Installation

FTN System Overview

Groups				Circuits															
Description	Circuits	Current	Capacity	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
FTTN DEFAULT GROUP	20	12mA	5140mA	382	381	380	379	379	380	382	382	381	381	n/a	n/a	n/a	n/a	n/a	n/a
FTTN GROUP 001	0	0mA	0mA	1	1	1	1	1	0	1	1	1	1	n/a	n/a	n/a	n/a	n/a	n/a
FTTN GROUP 002	0	0mA	0mA	379	383	379	382	381	380	381	379	382	384	n/a	n/a	n/a	n/a	n/a	n/a
FTTN GROUP 004	0	0mA	0mA	1	1	1	1	1	1	1	1	1	1	n/a	n/a	n/a	n/a	n/a	n/a
FTTN GROUP 005	0	0mA	0mA																

SH01 1.5 A
A 1-8 9-16 CB
B 1-8 9-16 CB
upper fan
lower fan


WEB



Front Panel

The web page reflects the physical configuration of each shelf.

The right hand side shows the 48V input current and alarm states for each of the DC inputs. Text changes to yellow for power minor and red for power major. Fan tray status is also alarmed on the right hand side of the figure. The output voltage and current of each circuit on each card is also shown on the physical representation of the shelf. The 'a' circuit output is shown on the top and the 'b' circuit output is shown below. The left hand side of the WEB display shows how circuits are grouped, including group name, number of circuits assigned, current draw, and current capacity.





[QS941A WEB Interface page 8]

Details about the WEB interface can be found in the QS941A Controller WEB Interface. This pdf document can be found at the bottom of the CPS2300U page located at: omnionpower.com

To help find the FTTN relevant information on each tab, please use this guide

(ovals show start links):



Maintenance:->
Clear missing devices declares the current state as good, retiring all alarms.

On/Standby control is available for FTTN starting here, too.

last updated 08:21:51

Settings:->
Details of FTTN setting can be found here

System	Reserve	Power	Communication	Programming
Plant	Battery Management	Rectifiers	Passwords	Auxiliary Inputs
Shelves	Temperature Compensation	Ringers	Security	User Defined Events
Shunts	Boost	Converters	Network	Derived Channels
Contactors	Battery Types	Part Numbers	Email	Periodic Call Out
FTTN	Battery Testing		Local Ports	
Time			Modem	
Display			Call Outs	
Alarm Test			Alarm Notification	
			TL1	

© 2006 Tyco Electronics Corporation. All rights reserved.

Installation:->
This is where one sets the date and time.

Confirm Equipment Installed

- 0 Rectifiers
- 0 Ringer Chassis
- 0 Ringers
- 0 Distribution Modules
- 0 Thermal Probes
- 0 Mid-String Probes

Set/Reset Default Battery Type Values

VALVE-REG

Submit Battery Type

Set Basic System Information

Enter the Site ID: 1

Set the date for this system: 08/28/2008

Set the time for this system: 08:33AM

Submit

Please note: loop resistance measurements only work for a small subset of applications.

To interact with the QS941 Controller through the WEB interface it is possible to connect a computer to the QS941A directly using server mode or through a LAN using client mode.

This section details how to set up the controller as either a server or a Client.

Change LAN to Server Mode

To access the controller directly from a PC, you must first change LAN connection to server mode.

Step	Action
1.	Press Menu or Accept key, ■.
2.	Press down arrow, ▼, to Configuration.
3.	Press the right arrow key, ► (or square "accept" key, ■) to advance.
4.	Press down arrow, ▼, to Communications Ports.
5.	Press the right arrow key, ► (or square "accept" key, ■) to advance.
6.	Press down arrow, ▼, to Network Settings.
7.	P Press the right arrow key, ► (or square "accept" key, ■) to advance.
8.	Press down arrow, ▼, to highlight DHCP.
9.	Press the right arrow key, ► (or square "accept" key, ■) to advance.
10.	Press down arrow, ▼, to toggle to SERVER.
11.	Press save, ■.
12.	Press the Back Arrow, ◀, to return to the default screen.
13.	Wait 2 minutes.
14.	Activate changes by removing the QS941 controller circuit card from the backplane. Wait until the LEDs extinguish.
15.	Reapply power by reinserting the circuit card connection until seated.
16.	Verify Server Mode by pressing Menu>Status>Network Settings>Port 1> to find 192.168.2.1 as the network address.

Warning: It is always safer to leave the controller in Client mode. This avoids LAN conflicts should the controller ever be connected to a Local Area Network.


Restore the LAN Connection to Client Mode

As good policy, always leave the controller in Client mode.

Step	Action
1.	Press Menu or Accept key, ■
2.	Press down arrow, ▼, to Configuration.
3.	Press the right arrow key, ► (or square “accept” key, ■) to advance.
4.	Press down arrow, ▼, to Communications Ports.
5.	Press the right arrow key, ► (or square “accept” key, ■) to advance.
6.	Press down arrow, ▼, to Network Settings.
7.	P Press the right arrow key, ► (or square “accept” key, ■) to advance.
8.	Press down arrow, ▼, to highlight DHCP.
9.	Press the right arrow key, ►(or square “accept” key, ■) to advance.
10.	Press down arrow, ▼, to toggle to CLIENT.
11.	Press save, ■ .
12.	Press the Back Arrow, ◀, to return to the default screen.
13.	Wait 2 minutes.
14.	Activate changes by removing the QS941 controller circuit card from the backplane. Wait until the LEDs extinguish.
15.	Reapply power by reinserting the circuit card connection until seated.
16.	Verify Client Mode by pressing Menu>Configuration>Communications Ports>NetworkSettings> to show Client mode.

This page intentionally left blank.

3. Front Panel




Home Reports Maintenance Settings Installation

FTTN System Overview

Groups				Circuits															
Description	Circuits	Current	Capacity	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
FTTN DEFAULT GROUP	20	12mA	5140mA	a v	382	381	380	379	379	380	382	382	381	381	n/a	n/a	n/a	n/a	n/a
FTTN GROUP 001	0	0mA	0mA	mA	1	1	1	1	1	0	1	1	1	1	n/a	n/a	n/a	n/a	n/a
FTTN GROUP 002	0	0mA	0mA	b v	379	383	379	382	381	380	381	379	382	384	n/a	n/a	n/a	n/a	n/a
FTTN GROUP 004	0	0mA	0mA	mA	1	1	1	1	1	1	1	1	1	1	n/a	n/a	n/a	n/a	n/a
FTTN GROUP 005	0	0mA	0mA																

SH01 1.5 A
A 1-8 9-16 CB
B 1-8 9-16 CB
upper fan
lower fan

WEB



Front Panel

Most of the detail needed to interact with the front panel is in the QS941A Controller User Interface document available from the website.

Key to getting started is understanding that the top row keys on the faceplate are soft keys. Text on the lower edge of the display indicates key function.



The QS941A Controller User Interface manual is the best reference to use when discussing interacting with the display with a customer. It can be found at this WEB address: omnionpower.com

Revision

Revision	Description	Date
1.2	Updated as per template	02/24/2022
1.3	Updated as per OmniOn template	12/14/2023

OmniOn Power Inc.

601 Shiloh Rd.
Plano, TX USA

[omnionpower.com](https://www.omnionpower.com)

We reserve the right to make technical changes or modify the contents of this document without prior notice. OmniOn Power does not accept any responsibility for errors or lack of information in this document and makes no warranty with respect to and assumes no liability as a result of any use of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of OmniOn Power. This document does not convey license to any patent or any intellectual property right. Copyright© 2023 OmniOn Power Inc. All rights reserved.