

PRODUCT MANUAL

Galaxy Pulsar Plus Controller Family

Troubleshooting Table with SMNP Traps

This document supplements CC848815341 Galaxy Pulsar Plus Controller Family Product Manual r07.

This page intentionally left blank

PRODUCT MANUAL

Table of Contents

Table of Contents	3
Contact Information	4
Troubleshooting Table.....	5

Contact Information

Phone: +-877-546-3243 (US)

E-mail: techsupport@elpc.omnion.com

Web site: omnionpower.com

Troubleshooting Table

Product Description and Customer Services

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
AMBER	MIN, AC Fail	ne843TrapDc1Acf	None	GREEN	<ul style="list-style-type: none"> Single Rectifier not receiving ac power . AC input circuit breaker has opened. AC input voltage is out of range. Rectifier or AC input fuse open. 	<ol style="list-style-type: none"> 1. Verify ac power to rectifier is available. 2. Verify rectifier input circuit breaker is closed. 3. If problem not corrected, replace rectifier.
RED	MIN, AC Fail MAJ, Multiple AC Fail MAJ, Battery on Discharge	ne843TrapDc1Macf ne843TrapDc1Bda	None	GREEN	<p>Multiple rectifiers not receiving ac power, batteries are powering load.</p> <ul style="list-style-type: none"> AC input circuit breakers have opened. AC input voltage is out of range. Internal rectifier fault. 	<ol style="list-style-type: none"> 1. Verify ac power to rectifiers is available. 2. Verify rectifier input circuit breakers are closed. 3. If problem not corrected, replace rectifier.
AMBER or RED	MIN, AC Fail MAJ, Multiple AC Fail	ne843TrapDc1Macf	None	GREEN	A rectifier, multiple rectifiers, or the entire system has lost AC.	<ol style="list-style-type: none"> 1. Verify that ac power to all rectifiers is available. 2. Verify that rectifiers all report good AC 3. Issue the uninstall equipment under the operations menu for any rectifier that may have been removed during the AC fail.
RED	MAJ, Battery on Discharge	ne843TrapDc1Bda	AC OK DC OK	GREEN	Rectifier output voltage has fallen below the battery on discharge threshold set by the user.	<ol style="list-style-type: none"> 1. If commercial ac power is present but the system voltage remains low, call your local field representative. 2. Investigate other alarms that may be present such as rectifier related problems.

¹ Display Backlight Color indicates alarm severity: Red = Critical or Major, Amber = Minor, Green = Normal.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
AMBER	MIN, Rectifier Fail (Note 1)	ne843TrapDc1Rfa ne843TrapDc1Rif ne843TrapDc1Bof ne843TrapDc1Sof	AC OK ALARM (Note 1)	GREEN	Rectifier output has dropped below 36V, rectifier has entered hiccup mode. Rectifier has an internal fault.	Replace rectifier.
RED	MAJ, Rectifier Fail	ne843TrapDc1Mfa	AC OK ALARM (Note 1)	GREEN	<ul style="list-style-type: none"> Two or more rectifier outputs have dropped below 36V, and have entered hiccup mode. Two or more rectifiers have internal faults. 	<ol style="list-style-type: none"> Verify that there is no obstruction of the airflow path. Reset the rectifier by removing the rectifier, waiting approximately 30 seconds, and replacing the rectifier. If problem persists, replace the rectifier. If problem still persists, call your local field representative.
RED	MAJ, Contactor Open (Note 1)	ne843TrapCnqCno(q is a number)	AC OK DC OK	RED	One or both of the LVD contactors is open; someone may have manually opened LVD contactor. Batteries have exceeded temperature threshold set by user.	<ol style="list-style-type: none"> Close contactors through the Control/Operations menu. Check system output voltage and LVD thresholds are correct. Verify contactor and contactor control board interface connections are appropriately connected. If problem still persists, call your local field representative.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
RED	MAJ, Contactor 1 Open	ne843TrapCn1Cno	AC OK DC OK	RED	One or both of the LVD contactors is open; someone may have manually opened LVD contactor. Batteries have exceeded temperature threshold set by user.	<ol style="list-style-type: none"> 1. Close contactors through the Control/Operations menu. 2. Check system output voltage and LVD thresholds are correct. 3. Verify contactor and contactor control board interface connections are appropriately connected. 4. If problem still persists, call your local field representative.
None	No response.	None. No response.	RED (Blinking)	RED (Blinking)	Controller failure, all devices on the communication bus reporting loss of communication with controller.	<ol style="list-style-type: none"> 1. Check controller to ensure it is properly inserted into its slot. If so, perform the following steps: 2. Remove the controller board for 1 minute and then reset. 3. If problem persists, replace controller with new controller board. 4. If problem still persists, call your local field representative.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
AMBER	MIN, Thermal ProbeFail	ne843TrapDcITpa	AC OK DC OK	GREEN	Battery thermal probe failed.	<ol style="list-style-type: none"> 1. Ensure thermal probe is properly connected to thermal probe cable and controller 2. Ensure cable is properly connected to the rear of the Distribution Module. 3. If problem persists, replace thermal probe per ensuing instructions. 4. If no thermal probe is desired make sure the Slope Thermal Compensation feature is disabled. 5. If problem still persists, call your local field representative.
RED	MAJ, Fuse Major	ne843TrapPsIFaj24 ne843TrapPsIFaj48	AC OK DC OK	RED	One or more of the output circuit breakers or fuses have opened.	Reset circuit breakers or replace fuse.
AMBER	MIN, Rectifier Fail	ne843TrapDcIRfa	AC OK ALARM	Normal	<ul style="list-style-type: none"> • Single rectifier failure • Single rectifier thermal shutdown 	<ol style="list-style-type: none"> 1. Verify that there is no obstruction of the airflow path. 2. Reset the rectifier by removing the rectifier, waiting approximately 30 seconds, and replacing the rectifier. 3. If problem persists, replace the rectifier. 4. If problem still persists, call your local field representative.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
RED	MIN, Rectifier Fail MAJ, Multiple Rectifier Fail MAJ, Battery on Discharge	ne843TrapDcIMfa ne843TrapDcIBda	AC OK ALARM	Normal	<ul style="list-style-type: none"> Multiple rectifier thermal alarm Excessive ambient temperature Multiple rectifier failure 	<ol style="list-style-type: none"> 1. Verify that there is no obstruction of the airflow path. 2. Reset rectifies by removing them, waiting approximately 30s and replacing them. 3. If problem persists, replace the rectifiers. 4. If problem still persists, call your local field representative.
RED	MAJ, High Voltage	ne843TrapDcIHva	AC OK ALARM	Normal	<ul style="list-style-type: none"> High output voltage from rectifier(s) Rectifier(s) high voltage shutdown Internal rectifier (s) failure HV threshold set below set point value. 	<ol style="list-style-type: none"> 1. Verify/correct HV threshold greater than set point value. 2. Reset the rectifier(s) by removing the rectifier(s), waiting approximately 30s and replacing the rectifier(s). 3. If problem persists, replace the rectifier. 4. If problem still persists, call your local field representative.
Amber	MIN, Clock Battery Low	ne843TrapPsIBbl	AC OK DC OK	Normal	Internal Lithium Battery Is Low	<ol style="list-style-type: none"> 1. The battery is not designed to be easily field replaced. The controller unit needs to be replaced. 2. Obtain all desired information such as alarm history, statistics, and any field configuration that is different than the standard.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
Amber	MIN, Minor, Communication Fail	ne843TrapDclCma	RED Blinking Single rectifier or other module	GREEN	Rectifier or other module lost communication with controller.	<ol style="list-style-type: none"> 1. If a module has been removed from an installed/operational system, go to the Control/Operations menu and execute Uninstall Equipment. 2. Reset the module by removing the module, waiting approximately 30 seconds, and replacing. 3. Verify/correct module to module cable. 4. If problem persists, replace the module. 5. If problem still persists, call your local field representative.
RED	MAJ, Major, Communication Fail	ne843TrapDclMcm	RED Blinking Single rectifier or other module	GREEN	Two or more rectifiers or other modules have lost communication with controller.	<ol style="list-style-type: none"> 1. If two or more modules have been removed from an installed/operational system, go to the Control/Operations menu and execute Uninstall Equipment. 2. Reset the modules by removing the modules, waiting approximately 30 seconds, and replacing. 3. Verify/correct module to module cable. 4. If problem persists, replace the modules. 5. If problem still persists, call your local field representative.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
GREEN	No Alarm, Individual Shunt Currents displayed at or above their maximum display values ($\geq 600A$ for loads, $\geq 800A$ for battery)	none	AC OK DC OK	Normal	One or both of the QS871A shunt inputs is open-circuit.	<ol style="list-style-type: none"> 1. Verify that the respective shunt has its green and yellow wire connections attached used for the current measurements. 2. Verify the shunt connection to the QS871A is good by verifying the green and yellow wire connections from the shunt follows through to the 10-pin connector at the respective QS871A.
Amber	Fuse Minor	ne843TrapPsIFan24 ne843TrapPsIFan48	AC OK DC OK	Green	One or more of the protectors assigned to Fuse Minor has opened.	Replace fuse or reset breaker.
None	ACO Active	ne843TrapAcoIAac	AC OK DC OK	Green	None (Informational)	
None	Alarm Test Aborted	ne843TrapAtIAtb	AC OK DC OK	Green	None (Informational)	
None	Alarm Test Active	ne843TrapAtIAta	AC OK DC OK	Green	None (Informational)	
RED	Auxiliary Event (event q)	ne843TrapPsIAxq (q is a number)	AC OK DC OK	Green	As event is defined	As event is defined
None	Battery Test Active	ne843TrapBrIBta	AC OK DC OK	Green	None (Informational)	
Amber	Battery Test Failed	ne843TrapBrIBfa	AC OK DC OK	Green	Battery test failed before completion.	Call your local field representative.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
None	Clock Changed	ne843TrapPsIClc	AC OK DC OK	Green	None (Informational)	
None	Configuration Changed	ne843TrapPsICch	AC OK DC OK	Green	None (Informational)	
None	Configuration Changed Reboot Required	ne843TrapPsICrt	AC OK DC OK	Green	Controller reboot Required	Reboot controller via front panel Control/Operations menu.
RED	Contactor Failed (contactor q)	ne843TrapCnqCnf (q is a number)	AC OK DC OK	Green	<ul style="list-style-type: none"> Control board wires are incorrect or disconnected Contactor or board failure. 	<ol style="list-style-type: none"> 1. Verify/correct control board wires. 2. Replace control board. 3. If problem still persists, call your local field representative to discuss replacing contactor.
RED	Contactor Open (contactor q)	ne843TrapCnqCno (q is a number)	AC OK DC OK	Green	<ul style="list-style-type: none"> One of disconnect contactor are open. Low Voltage Disconnect (LVD) and Low Voltage Load Disconnect (LVLD) contactors open and close when configured set points are reached. 	<ol style="list-style-type: none"> 1. Correct DC low voltage condition, if present. 2. Return contactor control switches to ON. 3. Set contactor to ON via controller. 4. If problem still persists, call your local field representative.
Amber	Converter Fail	ne843TrapCplCfa	AC OK DC OK	Green		Replace Converter
RED	Converter Fan Major	ne843TrapCplCfj	AC OK DC OK	Green		Replace Converter
Amber	Converter Fan Minor	ne843TrapCplCfn	AC OK DC OK	Green		Replace Converter

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
RED	Converter High Voltage Major	ne843TrapCp1Hva	AC OK DC OK	Green	One of more failed converters.	<ol style="list-style-type: none"> 1. Replace alarmed converters. 2. If alarm persists, Read out all inverter output currents. 3. Replace all inverters with output current much higher than the average 4. If problem still persists, call your local field representative.
Amber	Converter High Voltage Minor	ne843TrapCp1Hfv	AC OK DC OK	Green	One of more failed converters.	<ol style="list-style-type: none"> 1. Replace alarmed converters. 2. If alarm persists, Read out all inverter output currents. 3. Replace all inverters with output current much higher than the average 4. If problem still persists, call your local field representative.
Amber	Converter Input Fail	ne843TrapCp1Cin	AC OK DC OK	Green	One or more Converters not receiving DC power. <ul style="list-style-type: none"> • DC input circuit breaker has opened. • DC input voltage is out of range. 	<ol style="list-style-type: none"> 1. Turn on all converter DC input breakers. 2. Correct out of range DC input voltage.
RED	Converter Redundancy Loss	ne843TrapCp1RI	AC OK DC OK	Green	Available converter capacity is not sufficient to support the load if a converter were to fail. <ul style="list-style-type: none"> • One or more converters is in Standby • Converter load has increased. 	<ol style="list-style-type: none"> 1. Set all converters to ON 2. Install additional converters

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
CRITRED	Converter Very Low Voltage	ne843TrapCpIVla	AC OK DC OK	Green	Available converter capacity is not sufficient to support the load if a converter were to fail. <ul style="list-style-type: none"> One or more converters is in Standby Converter load has increased. 	1. Set all converters to ON 2. Install additional converters
RED	Distribution Fail	ne843TrapCpIDfa	AC OK DC OK	Green	Fuse or circuit breaker has open in the integrated converter chassis.	Examine load situation Reset breaker or replace fuse.
RED	Emergency Power Off	ne843TrapDcIEpo	AC OK DC OK	Green	Emergency Power Off external input is asserted – external switch is in EPO mode.	Reset external EOP switch to normal.
None	Energy Management Disabled	ne843TrapDcIEmd	AC OK DC OK	Green	None (Informational)	
None	Excessive Login Attempts	ne843TrapPsIExl	AC OK DC OK	Green	None (Informational)	
None	External Password Reset	ne843TrapPsIEpr	AC OK DC OK	Green	None (Informational)	
RED	Generator Fail	ne843TrapGnIGnf	AC OK DC OK	Green	Alarm received from generator	Troubleshoot generator.
RED	Generator Maintenance Required	ne843TrapGnIGnm	AC OK DC OK	Green	Generator maintenance is due.	Perform generator maintenance.
Amber	Generator Running	ne843TrapGnIGnr	AC OK DC OK	Green	None (Informational)	
None	Generator Start	ne843TrapGnIGns	AC OK DC OK	Green	None (Informational)	

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
Amber	High Ambient Temperature	ne843TrapPsIAmth	AC OK DC OK	Green	<ul style="list-style-type: none"> Cooling system failure High external temperature Ambient temp probe location improper Temperature threshold too low 	<ol style="list-style-type: none"> Verify/repair cooling system. Verify/correct ambient temp threshold and probe operation. Verify probe location.
Amber	High Battery Temperature	ne843TrapBrIBtha	AC OK DC OK	Green	Excessive float current due to defective battery.	Troubleshoot batteries.
Amber	High Float Voltage	ne843TrapDcIHfv	AC OK DC OK	Green	One of more rectifiers not regulating and load sharing.	Replace rectifiers operating at much higher current than the others.
None	History Cleared	ne843TrapPsIHcl	AC OK DC OK	Green	None (Informational)	
RED	ID Conflict	ne843TrapDcIDid	AC OK DC OK	Green	Two or more rectifier shelves have the same (non-unique) IDs.	Set ID switches on all rectifier shelves so that each shelf has a unique ID.
RED	ID Conflict	ne843TrapCpIDid	AC OK DC OK	Green	Two or more converter shelves have the same (non-unique) IDs.	Set ID switches on all converter shelves so that each shelf has a unique ID.
RED	ID Not Configured	ne843TrapDcIZid	AC OK DC OK	Green	One or more power units have the same unconfigured IDs.	Configure IDs on all connected units at the shelf or module as appropriate.
RED	Imminent Shutdown	ne843TrapBrIIsda	AC OK DC OK	Green	Rectifiers or converters are about to turn OFF due to low input voltage (Informational).	None required.
Amber	Incompatible Converter Alarm	ne843TrapCpIicc	AC OK DC OK	Green	One or more installed converters are not compatible with the system. Converter is not same output voltage.	Replace incompatible converters with compatible converters.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
Amber	Incompatible Rectifier	ne843TrapDcIllcr	AC OK DC OK	Green	One or more installed rectifiers are not compatible with the system. Rectifier is not same output voltage.	Replace incompatible rectifiers with compatible rectifiers with the same output voltage.
RED	Inverter Distribution Alarm	ne843Traplvpllda	AC OK DC OK	Green	One or more of the inverter AC distribution circuit breakers have opened.	Reset circuit breakers.
RED	Inverter Fail	ne843Traplvpllf	AC OK DC OK	Green	Inverter failed.	Replace inverter
RED	Inverter Frequency Lock	ne843Traplvpllfa	AC OK DC OK	Green	Inverters unable to synchronize with AC mains.	Call your local field representative.
Amber	Inverter High Crest Factor	ne843Traplvpllcf	AC OK DC OK	Green	Inverter high output crest factor due to <ul style="list-style-type: none"> Insufficient inverters for non-linear inverter load. Defective inverter. 	<ol style="list-style-type: none"> Read out and note crest factor Add an inverter. Read out crest factor. If crest factor is reduced, continue adding inverters until alarm no longer occurs. If crest factor is not reduced, replace inverters one at a time until crest factor is reduced. Last inverter removed is defective. If problem still persists, call your local field representative.
RED	Inverter High Input	ne843Traplvpllhvi	AC OK DC OK	Green	High inverter DC input voltage.	Trouble shoot inverter DC input voltage.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
RED	Inverter High Output	ne843Traplvpllhv	AC OK DC OK	Green	One or more failed inverters.	<ol style="list-style-type: none"> 1. Read out all inverter output currents. 2. Replace all inverters with output current much higher than the average 3. If problem still persists, call your local field representative.
Amber	Inverter High Peak Current	ne843Traplvpllipk	AC OK DC OK	Green	Inverter high output peak current due to <ul style="list-style-type: none"> • Insufficient inverters for non-linear inverter load. • Defective inverter. 	<ol style="list-style-type: none"> 5. Read out and note peak current 6. Add an inverter. 7. Read out crest factor. 8. If peak current is reduced, continue adding inverters until alarm no longer occurs. <p>If peak current is not reduced, replace inverters one at a time until crest factor is reduced. Last inverter removed is defective.</p> <p>If problem still persists, call your local field representative.</p>

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
Amber	Inverter High RMS Current	ne843TrapIvpIirm	AC OK DC OK	Green	Inverter high output RMS current due to <ul style="list-style-type: none"> Insufficient inverters for non-linear inverter load. Defective inverter. 	<ol style="list-style-type: none"> Read out and note RMS current Add an inverter. Read out crest factor. If RMS current is reduced, continue adding inverters until alarm no longer occurs. <p>If RMS current is not reduced, replace inverters one at a time until crest factor is reduced. Last inverter removed is defective.</p> <ol style="list-style-type: none"> If problem still persists, call your local field representative.
RED	Inverter High Temperature	ne843TrapIvpIIta	AC OK DC OK	Green	<ul style="list-style-type: none"> Blocked inverter vents High ambient temperature Defective inverter 	<ol style="list-style-type: none"> Clear inverter vents Reduce ambient temperature Replace defective inverter
RED	Inverter ID Conflict	ne843TrapIvpIIdid	AC OK DC OK	Green	Two or more inverters have the same (non-unique) IDs.	Set inverter IDs on all inverters so that each shelf has a unique ID.
Amber	Inverter Low Input	ne843TrapIvpIIlvi	AC OK DC OK	Green	<ul style="list-style-type: none"> Low DC source voltage High voltage drop in input cables 	Trouble shoot inverter DC input voltage.
Amber	Inverter Low Output	ne843TrapIvpIIlv	AC OK DC OK	Green	Load exceeds inverter capacity	Add inverters.
RED	Inverter Output Fuse	ne843TrapIvpIlof	AC OK DC OK	Green	Failed inverter.	Replace inverter.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
Amber	Inverter Redundancy Loss	ne843TrapIvpIrls	AC OK DC OK	Green	Available inverter capacity is not sufficient to support the load if an inverter were to fail. <ul style="list-style-type: none"> One or more inverters is in Standby Inverter load has increased. 	<ol style="list-style-type: none"> Set all inverters to ON Install additional inverters
Amber	Load Share Fail	ne843TrapDclLsf	AC OK DC OK	Green	One or more rectifiers' output current is not near the average.	<ol style="list-style-type: none"> Remove and reinstall rectifier. If problem still persists, replace rectifier.
Amber	Low Ambient Temperature	ne843TrapPsIAmtl	AC OK DC OK	Green	<ul style="list-style-type: none"> Heating system failure Low external temperature Ambient temp probe location improper Temperature threshold too high 	<ol style="list-style-type: none"> Verify/repair heating system. Verify ambient temp threshold. Verify/correct probe location.
None	Low Battery Temperature	ne843TrapBrIBtla	AC OK DC OK	Green	(Informational)	
Amber	Manual Off	ne843TrapDclMan	AC OK DC OK	Green	One rectifier is manually held off (standby).	Set the rectifier to ON
Amber	Memory Backup Battery Low	ne843TrapPsIBbl	AC OK DC OK	Green	On-board memory battery/RTC near end of life.	Replace battery with exact battery module. Consult technical support for part needed.
RED	Multiple Converter Fail	ne843TrapCpIMfa	AC OK DC OK	Green	<ul style="list-style-type: none"> Multiple converter thermal alarm Obstruction of airflow path. Excessive ambient temperature Multiple converter failure 	<ol style="list-style-type: none"> Remove obstructions of the airflow path. Reset converters by removing them, waiting approximately 30s and replacing them. If problem persists, replace the converters. If problem still persists, call your local field representative.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
RED	Multiple Converter Fail	ne843TrapCp1Mfa	AC OK DC OK	Green	<ul style="list-style-type: none"> Multiple converter thermal alarm Obstruction of airflow path. Excessive ambient temperature Multiple converter failure 	<ol style="list-style-type: none"> Remove obstructions of the airflow path. Reset converters by removing them, waiting approximately 30s and replacing them. If problem persists, replace the converters. If problem still persists, call your local field representative.
RED	Multiple Inverter Fail	ne843TrapIvp1Mif	AC OK DC OK	Green	<ul style="list-style-type: none"> Multiple inverter thermal alarm Obstruction of airflow path. Excessive ambient temperature Multiple inverter failure 	<ol style="list-style-type: none"> Remove obstructions of the airflow path. Reset inverters by removing them, waiting approximately 30s and replacing them. If problem persists, replace the inverters. If problem still persists, call your local field representative.
RED	Multiple Manual Off	ne843TrapDc1Mman	AC OK DC OK	Green	One or more rectifiers is manually held off (standby).	Set the rectifiers to ON
None	Number Did Not Respond	ne843TrapCm1Cor	AC OK DC OK	Green	Modem dialed number did not answer.	<ol style="list-style-type: none"> Verify/correct configured number. Verify/repair phone line connection.
None	Number Did Not Respond	ne843TrapPo1Por	AC OK DC OK	Green	Modem dialed number did not answer.	<ol style="list-style-type: none"> Verify/correct configured number. Verify/repair phone line connection.
None	Number Not Configured	ne843TrapCm1Nnc	AC OK DC OK	Green	Modem periodic dialed number not configured.	Verify and configure number.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
RED	Open String	ne843TrapDcIOsa	AC OK DC OK	Green	One of more battery strings are disconnected via contactor, switch, breaker, or fuse.	<ol style="list-style-type: none"> 1. Return switch or breaker to ON. 2. Replace fuse. 3. Return contactor control switches to ON. 4. Set contactor to ON via controller. 5. If problem still persists, call your local field representative.
None	Passwords At Default	ne843TrapPsIPfd	AC OK DC OK	Green	None (informational)	
RED	Probe Minimum Fail	ne843TrapDcIPmf	AC OK DC OK	Green	Ambient temp probe failed or disconnected.	<ol style="list-style-type: none"> 1. Verify at least 2 ambient temp probes. 2. Verify/repair probe connections. 3. Replace suspect probe.
RED	Program Line Invalid	ne843TrapPsIPgi	AC OK DC OK	Green	User defined event or parameter is invalid.	Correct program line.
RED	Queue Overflow	ne843TrapCmICof	AC OK DC OK	Green	Controller program execution error.	<ol style="list-style-type: none"> 1. Cycle power to controller. 2. If problem still persists, replace controller.
None	Real-time ReserveTime Low	ne843TrapDcIRtl	AC OK DC OK	Green	Battery reserve time is low during a discharge. (informational)	<ol style="list-style-type: none"> 1. Verify/correct battery settings. 2. Verify reserve time vs load. 3. Check battery.
None	Rectifier Current Limit	ne843TrapDcIClm	AC OK DC OK	Green	One or more rectifiers are in current limit. (informational)	<ol style="list-style-type: none"> 1. Verify sufficient rectifier capacity for load and battery recharge. 2. Rectifier current limit is normal during battery recharge.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
Amber	Rectifier Fan Failure	ne843TrapDclRfn	AC OK DC OK	Green	Rectifier fan failed.	Replace rectifier.
Amber	Rectifier Internal Fault	ne843TrapDclRif	Alarm		Rectifier output has dropped below 36V, rectifier has entered hiccup mode. Rectifier has an internal fault.	Replace rectifier.
Amber	Rectifier ORing FET Fault	ne843TrapDclBof	Alarm		Rectifier ORing FET fault	Replace rectifier.
Amber	Rectifier Shorted ORing FET	ne843TrapDclSof	Alarm		Rectifier ORing FET fault	Replace rectifier.
Amber	Rectifier Under Voltage	ne843TrapDclDer	Alarm		Output of rectifier internally forced low.	Replace rectifier.
Amber	Redundancy Loss	ne843TrapDclRls	AC OK DC OK	Green	<ul style="list-style-type: none"> Available rectifier capacity is not sufficient to support the load if a rectifier were to fail per configured redundancy loss threshold. Rectifier load has increased. One or more rectifiers are in standby. 	<ol style="list-style-type: none"> Set all rectifiers to ON. Install additional rectifiers. Verify/correct configured redundancy loss threshold.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
None	Reserve Time Low	ne843TrapDcIRtl	AC OK DC OK	Green	Battery reserve time is low on float. (informational)	1.Verify/correct battery configuration. 2.Verify reserve capacity vs. load 3.Check batteries.
RED	Reverse Battery	ne843TrapBrIRba	AC OK DC OK	Green	Battery polarity is reversed.	Correct polarity of battery connections.
Amber	Ringer Fan Fail	ne843TrapRpIRpff	AC OK DC OK	Green	Ringer fan fail.	Replace fan.
RED	Ringer ID Conflict	ne843TrapRpIRcd p	AC OK DC OK	Green	Two or more ringer modules have the same (non-unique) IDs.	Set IDs switches on all ringer modules so that each has a unique ID.
RED	Ringer Major External Fault	ne843TrapRpIRpxj	AC OK DC OK	Green	Short or overload on ringer output.	Clear short or overload.
RED	Ringer Major Fail	ne843TrapRpIRpfj	AC OK DC OK	Green	Ringer module fail.	Replace ringer module.
Amber	Ringer Minor External Fault	ne843TrapRpIRpx n	AC OK DC OK	Green	Overload on ringer output.	Clear overload.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
Amber	Ringer Minor Fail	ne843TrapRpIRf	AC OK DC OK	Green	Ringer failed, but ringing output continues to function satisfactorily.	Replace ringer module.
Amber	Ringer Redundancy Loss	ne843TrapRpIRpl	AC OK DC OK	Green	<ul style="list-style-type: none"> Available ringer capacity is not sufficient to support the load if a ringer were to fail. One or more ringers has failed Ringer load has increased. 	<ol style="list-style-type: none"> Rebalance ringer loads. Install additional ringer.
Amber	Self Test Failed	ne843TrapPsIStf	AC OK DC OK	Green	Controller self test failed.	Replace controller.
Amber	Sense/Control Fuse	ne843TrapDcIVsf	AC OK DC OK	Green	Sense or control fuse failed.	<ol style="list-style-type: none"> Replace sense or control fuse. Verify remote sense wires are connected to appropriate points.
Amber	Shorted Cell Detected	ne843TrapBrIScda	AC OK DC OK	Green	Shorted battery cell detected. Battery Probe not placed in proper location in the string.	<ol style="list-style-type: none"> Verify/repair connections. Check batteries. Generally, all cells in a string should be replaced together.
RED	Thermal Probe Fail Safe	ne843TrapDcIPfs	AC OK DC OK	Green	Battery thermal probe <ul style="list-style-type: none"> disconnected failed 	<ol style="list-style-type: none"> Verify/repair probe connections Verify number of probes matches settings Update Equipment – Controller menu Replace probe and verify system output voltage returns to normal set-point.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
As user defined	This may be a userdefined event, or anew controller event.	ne843TrapUserDefined	AC OK DC OK	Green	As user defined	As user defined
None	Very High Battery Temperature	ne843TrapBr1Btvh	AC OK DC OK	Green	Battery temperature is very high (informational)	
None	Very Low Battery Temperature	ne843TrapBr1Btvl	AC OK DC OK	Green	Battery temperature is very low (informational)	
RED	Very Low Voltage	ne843TrapDc1Vla	AC OK DC OK	Green	DC voltage is almost too low to operate equipment. <ul style="list-style-type: none"> Battery on discharge Available rectifier capacity not sufficient Alarm threshold configured above set point 	<ol style="list-style-type: none"> Restore AC power Bring generator on -line. Connect fresh batteries. Install more rectifiers. Verify output voltage and alarm threshold.
RED	Voltage Duplicate ID	ne843TrapBr1Mdp	AC OK DC OK	Green	Two ES771 modules have same ID	Change ID settings so that modules have unique, non-zero values.
RED	Voltage ID Not Configured	ne843TrapBr1Mzd	AC OK DC OK	Green	ID not set on ES771.	Set IDs to unique, non-zero values.

Display Backlight Color ¹	User Interface Display	SNMP Trap	Rectifier LED	Distribution Module Board LED	Possible Problem(s)	Possible Solution(s)
Amber	Voltage Module Fail	ne843TrapDcIVmf	AC OK DC OK	Green	<ul style="list-style-type: none"> ES771 failure ES771 disconnected 	<ol style="list-style-type: none"> Verify ES771 connections. Verify/replace ES771.

Table 1 Infinity NE System Troubleshooting

Note 1: While in hiccup mode, the rectifier will attempt to restart every 10 seconds for a maximum of 3 times.

Note 2: Refer to Section 5, LVD board Removal for removal details. Note that the power system will continue to power the load while the LVD board is out of the system; however, there will be no possibility of battery backup until the LVD board is replaced.

OmniOn Power Inc.

601 Shiloh Rd.
Plano, TX USA

omnionpower.com

We reserve the right to make technical changes or modify the contents of this document without prior notice. OmniOn Power does not accept any responsibility for errors or lack of information in this document and makes no warranty with respect to and assumes no liability as a result of any use of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of OmniOn Power. This document does not convey license to any patent or any intellectual property right. Copyright© 2023 OmniOn Power Inc. All rights reserved.