

#### **DATASHEET**


# **20A Digital MicroDLynx**<sup>TM</sup>: Non-Isolated DC-DC Power Modules

3V<sub>dc</sub> –14.4V<sub>dc</sub> input; 0.45V<sub>dc</sub> to 5.5V<sub>dc</sub> output; 20A Output Current



#### **Description**

The 20A Digital MicroDLynx™ power modules are non-isolated dc-dc converters that can deliver up to 20A of output current. These modules operate over a wide range of input voltage ( $V_{IN} = 3V_{dc}-14.4V_{dc}$ ) and provide a precisely regulated output voltage from 0.6V<sub>dc</sub> to 5.5V, programmable via an external resistor and PMBus™ control. Features include a digital interface using the PMBus™ protocol, remote On/Off, adjustable output voltage, over current and over temperature protection. The PMBus™ # interface supports a range of commands to both control and monitor the module. The module also includes the Tunable Loop` feature that allows the user to optimize the dynamic response of the converter to match the load with reduced amount of output capacitance leading to savings on cost and PWB area.



#### **Applications**

- Distributed power architectures
- Intermediate bus voltage applications
- Telecommunications equipment
- Servers and storage applications
- Networking equipment
- Industrial equipment

See Footnote on Page 2



#### **Features**

- Compliant to RoHS Directive 2011/65/EU and amended Directive (EU) 2015/863.
- Compliant to REACH Directive (EC) No 1907/2006
- Use OmniOn specified module version and process for SMT placement on bottom side of board (-D version only)
- Compatible in a Pb-free or SnPb reflow environment (Z versions)
- Compliant to IPC-9592 (September 2008), Category 2, Class II
- DOSA based
- Wide Input voltage range (3Vdc-14.4V<sub>dc</sub>)
- Output voltage programmable from 0.45V<sub>dc</sub> to 5.5V<sub>dc</sub> via external resistor and PMBus<sup>TM</sup> #
- Digital interface through the PMBus™ # protocol
- Tunable Loop™ to optimize dynamic output voltage response
- Flexible output voltage sequencing EZ-SEQUENCE

- Power Good signal
- Fixed switching frequency with capability of external synchronization
- Output over current protection (non-latching)
- Over temperature protection
- Remote On/Off
- Ability to sink and source current
- Cost efficient open frame design
- Small size: 20.32 mm x 11.43 mm x 8.5 mm (0.8 in x 0.45 in x 0.334 in)
- Wide operating temperature range [-40°C to 105°C (Ruggedized: -D), 85°C(Regular)]
- ANSI/UL\* 62368-1 and CAN/CSA† C22.2 No. 62368-1 Recognized, DIN VDE‡ 0868-1/A11:2017 (EN62368-1:2014/A11:2017)
- ISO\*\* 9001 and ISO 14001 certified manufacturing facilities

#### FOOTNOTES

<sup>\*</sup> UL is a registered trademark of Underwriters Laboratories, Inc.

<sup>&</sup>lt;sup>†</sup> CSA is a registered trademark of Canadian Standards Association.

<sup>&</sup>lt;sup>‡</sup> VDE is a trademark of Verband Deutscher Elektrotechniker e.V.

<sup>\*\*</sup> ISO is a registered trademark of the International Organization of Standards

 $<sup>^{\</sup>sharp}$  The PMBus name and logo are registered trademarks of the System Management Interface Forum (SMIF)



## **Technical Specifications**

### **Absolute Maximum Ratings**

Stresses in excess of the absolute maximum ratings can cause permanent damage to the device. These are absolute stress ratings only, functional operation of the device is not implied at these or any other conditions in excess of those given in the operations sections of the data sheet. Exposure to absolute maximum ratings for extended periods can adversely affect the device reliability.

Parameter Parame	Device	Symbol	Min	Max	Unit
Input Voltage	All	V <sub>IN</sub>	-0.3	15	V
Continuous	All	VIN	-0.5	15	V
SEQ, SYNC, VS+	All			7	V
CLK, DATA, SMBALERT#	All			3.6	V
Operating Ambient Temperature (see Thermal Considerations section)	All	T <sub>A</sub>	-40	105	°C
Storage Temperature	All	$T_{stg}$	-55	125	°C

### **Electrical Specifications**

Unless otherwise indicated, specifications apply over all operating input voltage, resistive load, and temperature conditions.

Parameter	Device	Symbol	Min	Тур	Max	Unit
Operating Input Voltage	All	$V_{IN}$	3	-	14.4	$V_{dc}$
Maximum Input Current $(V_{IN} = 3V \text{ to } 14V, I_O = I_{O, max})$	All	I <sub>IN,max</sub>			19	A <sub>dc</sub>
Input No Load Current	$V_{O, set} = 0.6 V_{dc}$	I <sub>IN,no load</sub>		69		mA
$(V_{IN} = 12V_{dc}, I_O = 0, module enabled)$	$V_{O, set} = 5V_{dc}$	I <sub>IN,no load</sub>		134		mA
Input Stand-by Current $(V_{IN} = 12V_{dc}, module disabled)$	All	I <sub>IN, stand-by</sub>		16.4		mA
Inrush Transient	All	l²t			1	$A^2s$
Input Reflected Ripple Current, peak-to-peak (5Hz to 20MHz, 1µH source impedance; V <sub>IN</sub> =0 to 14V I <sub>O</sub> = I <sub>o max</sub> ; see Test configuration section)	All			50		mA <sub>p-p</sub>
Input Ripple Rejection (120Hz)	All			-64		dB
Output Voltage Set-point (with 0.1% tolerance for external resistor used to set output voltage)	All	$%V_{O,set}$	-1.0		+1.0	%V <sub>O, set</sub>
Output Voltage (Over all operating input voltage, resistive load, and temperature conditions until end of life)	All	$%V_{O,set}$	-3.0		+3.0	%V <sub>O, set</sub>
Adjustment Range (selected by an external resistor)						
(Some output voltages may not be possible depending on the input voltage – see Feature Descriptions Section)	All	Vo	0.6		5.5	V <sub>dc</sub>
PMBus Adjustable Output Voltage Range	All	$V_{O,adj}$	-25	0	+25	$%V_{O,set}$
PMBus Output Voltage Adjustment Step Size	All		0.4			$%V_{O, set}$

UDT020\_DS



Rev. 2.10

## **Technical Specifications** (continued)

## **Electrical Specifications** (continued)

Parameter	Device	Symbol	Min	Тур	Max	Unit
Remote Sense Range	All				0.5	$V_{dc}$
Output Regulation (for V <sub>O</sub> ≥ 2.5V <sub>dc</sub> )						
Line $(V_{IN}=V_{IN, min} \text{ to } V_{IN, max})$	All		±0.17	±0.27	±0.4	$%V_{O, set}$
Load (I <sub>O</sub> =I <sub>O, min</sub> to I <sub>O, max</sub> )	All			-	10	mV
Output Regulation (for V <sub>O</sub> < 2.5V <sub>dc</sub> )						
Line (V <sub>IN</sub> =V <sub>IN, min</sub> to V <sub>IN, max</sub> )	All			-	5	mV
Load (Io=Io, min to Io, max)	All			-	10	mV
Temperature ( $T_{ref}=T_{A, min}$ to $T_{A, max}$ )	All			-	0.4	$%V_{O,  set}$
Output Ripple and Noise on nominal output						
$(V_{IN}=V_{IN}, _{nom} \text{ and } I_{O}=I_{O}, _{min} \text{ to } I_{O}, _{max} C_{o} = 0.1 \mu F // 22 \mu F$						
ceramic capacitors)						
Peak-to-Peak (5MHz to 20MHz bandwidth)	All		-	50	100	$mV_{pk-pk}$
RMS (5MHz to 20MHz bandwidth)	All			20	38	$mV_{rms}$
External Capacitance <sup>1</sup>						
Without the Tunable Loop™						
ESR ≥ 1 mΩ	All	C <sub>O, min</sub>	2x47	-	2x47	μF
With the Tunable Loop™						
ESR ≥ 0.15 mΩ	All	C <sub>O, max</sub>	2x47	-	1000	μF
ESR ≥ 10 mΩ	All	C <sub>O, max</sub>	2x47	-	10000	μF
Output Current (in either sink or source mode)	All	l <sub>o</sub>	0		20	$A_{dc}$
Output Current Limit Inception (Hiccup Mode)	All	I <sub>O, lim</sub>	110	130	150	% I <sub>o.max</sub>
(current limit does not operate in sink mode)	All	IO, IIM	110	150	150	70 To,max
Output Short-Circuit Current ( $V_0 \le 250$ mV) ( Hiccup Mode )	All	I <sub>O, s/c</sub>	1.4	2.5	3.6	$A_{rms}$
Efficiency	V <sub>O, set</sub> = 0.6 V <sub>dc</sub>	η	76.0	79.1		%
$V_{IN} = 12V_{dc}, T_A = 25^{\circ}C$	V <sub>O, set</sub> = 1.2 V <sub>dc</sub>	η	84.3	87.1		%
$I_0 = I_0$ , max, $V_0 = V_0$ , set	V <sub>O, set</sub> = 1.8 V <sub>dc</sub>	η	87.2	90.4		%
	$V_{0, set} = 2.5 V_{dc}$	ή	90.3	92.6		%
	$V_{O, set} = 3.3 V_{dc}$	η	91.4	93.8		%
	$V_{O, set} = 5.0 V_{dc}$	η	92.8	95.2		%
Switching Frequency	All	f <sub>sw</sub>	475	500	525	kHz
Frequency Synchronization	All	- 500				
Synchronization Frequency Range	All		425		600	kHz
High-Level Input Voltage	All	VIH	2.0			V
Low-Level Input Voltage	All	V <sub>IL</sub>	2.0		0.4	V
Input Current, SYNC	All				100	nA
		I <sub>SYNC</sub>	100		100	
Minimum Pulse Width, SYNC	All	t <sub>SYNC</sub>	100			ns
Maximum SYNC rise time	All	t <sub>sync_sh</sub>	100			ns

<sup>&</sup>lt;sup>1</sup> External capacitors may require using the new Tunable LoopTM feature to ensure that the module is stable as well as getting the best transient response. See the Tunable LoopTM section for details.

## **General Specifications**

Parameter	Device	Min	Тур	Max	Unit
Calculated MTBF (I <sub>O</sub> =0.8 I <sub>O</sub> , <sub>max</sub> , T <sub>A</sub> =40°C) Telcordia Issue 2 Method 1 Case 3	All		15,455,614		Hours
Weight		4.086 (0.14)	4.54 (0.16)		g (oz.)



## **Feature Specifications**

Unless otherwise indicated, specifications apply over all operating input voltage, resistive load, and temperature conditions. See Feature Descriptions for additional information.

Parameter	Device	Symbol	Min	Тур	Max	Unit
On/Off Signal Interface						
(V <sub>IN</sub> =V <sub>IN, min</sub> to V <sub>IN, max</sub> ; open collector or equivalent, Signal						
referenced to GND)						
Device Code with no suffix "4" – Positive Logic						
(See Ordering Information)						
Logic High (Module ON)						
Input High Current	All	I <sub>IH</sub>		_	1	mA
Input High Voltage	All	VIH	2	_	$V_{IN,max}$	V
Logic Low (Module OFF)					,	
Input Low Current	All	I <sub>IL</sub>	-	-	1	mΑ
Input Low Voltage	All	VIL	-0.2	-	0.6	V
Device Code with no suffix – Negative Logic						
(See Ordering Information)						
(On/OFF pin is open collector/drain logic input with						
external pull-up resistor; signal referenced to GND)						
Logic High (Module OFF)						
Input High Current	All	I <sub>IH</sub>	-	-	1	mΑ
Input High Voltage	All	VIH	2	-	$V_{IN,max}$	$V_{dc}$
Logic Low (Module ON)						
Input low Current	All	I <sub>IL</sub>	-	-	10	μA
Input Low Voltage	All	VIL	-0.2	-	0.6	$V_{dc}$
Turn-On Delay and Rise Times						
$(V_{IN}=V_{IN, nom}, I_O=I_O, max, V_O \text{ to within } \pm 1\% \text{ of steady state})$						
Case 1: On/Off input is enabled and then input power is						
applied (delay from instant at which $V_{IN} = V_{IN,min}$ until	All	$T_{delay}$	0.8	1.1	1.7	msec
$V_0 = 10\%$ of $V_0$ , set)	7	. delay	0.0		,	
Case 2: Input power is applied for at least one second						
and then the On/Off input is enabled (delay from instant	All	T <sub>delay</sub>	600	700	1800	µsec
at which $V_{on/Off}$ is enabled until $V_o = 10\%$ of $V_{o, set}$ )						
Output voltage Rise time (time for V <sub>o</sub> to rise from 10% of		_				
V <sub>o, set</sub> to 90% of V <sub>o, set</sub> )	All	T <sub>rise</sub>	1.2	1.5	2.7	msec
Output voltage overshoot (T <sub>A</sub> = 25°C						
V <sub>IN</sub> = V <sub>IN</sub> , min to V <sub>IN</sub> , max, Io = Io, min to Io, max)					3.0	$\% V_{O,  set}$
With or without maximum external capacitance						0,300
Over Temperature Protection (See Thermal Considerations		T <sub>ref</sub> -Q1	123	133	143	°C
section)	All	T <sub>ref</sub> -Q4	121	131	141	°C
PMBus Over Temperature Warning Threshold*	All	T <sub>WARN</sub>	120	130	140	°C
Tracking Accuracy ( $V_{IN, min}$ to $V_{IN, max}$ ; $I_{O, min}$ to $I_{O, max}$ $V_{SEQ} < V_{O}$ )		- WARIN			1.5	
(Power-Up: 2V/ms)	All	V <sub>SEQ</sub> – V <sub>o</sub>			100	mV
(Power-Down: 2V/ms)	All	V <sub>SEQ</sub> - V <sub>o</sub>			100	mV
Input Undervoltage Lockout	7 111	* SEQ VO			100	1117
Turn-on Threshold	All		2.7		2.95	$V_{dc}$
Turn-off Threshold	All		2.7		2.95	V <sub>dc</sub>
	All		0.05		0.4	
Hysteresis PMBus Adjustable Input Under Voltage Lockout	All		0.05		0.4	$V_{dc}$
Thresholds	All		2.5		14	$V_{dc}$
Resolution of Adjustable Input Under Voltage Threshold	All				500	mV
	, 111	i .	l	<u> </u>		1117

<sup>\*</sup> Over temperature Warning – Warning may not activate before alarm and unit may shutdown before warning

Rev. 2.10



## Feature Specifications (continued)

Parameter	Device	Symbol	Min	Тур	Max	Unit
PGOOD (Power Good)						
Signal Interface Open Drain, V <sub>supply</sub> ≤ 5V <sub>DC</sub>						
Overvoltage threshold for PGOOD ON	All		103	108	113	$\%$ $V_{O, set}$
Overvoltage threshold for PGOOD OFF	All		100	105	110	% V <sub>O, set</sub>
Undervoltage threshold for PGOOD ON	All		105	110	115	% V <sub>O, set</sub>
Undervoltage threshold for PGOOD OFF	All		85	90	95	% V <sub>O, set</sub>
Pulldown resistance of PGOOD pin	All				50	Ω
Sink current capability into PGOOD pin	All				2	mA

## **Digital Interface Specifications**

Unless otherwise indicated, specifications apply over all operating input voltage, resistive load, and temperature conditions. See Feature Descriptions for additional information.

Parameter	Conditions	Symbol	Min	Тур	Max	Unit
PMBus Signal Interface Characteristics						
Input High Voltage (CLK, DATA)		V <sub>IH</sub>	2.1		3.6	V
Input Low Voltage (CLK, DATA)		V <sub>IL</sub>			0.8	V
Input high level current (CLK, DATA)		I <sub>IH</sub>	-10		10	μA
Input low level current (CLK, DATA)		I <sub>IL</sub>	-10		10	μA
Output Low Voltage (CLK, DATA, SMBALERT#)	I <sub>out</sub> =2mA	$V_{OL}$			0.4	V
Output high level open drain leakage current (DATA, SMBALERT#)	V <sub>OUT</sub> =3.6V	Іон	0		10	μA
Pin capacitance		Co		0.7		рF
PMBus Operating frequency range	Slave Mode	F <sub>PMB</sub>	10		400	kHz
Data hald time	Receive Mode	_	0			
Data hold time	Transmit Mode	t <sub>hD:DAT</sub>	300			ns
Data setup time		t <sub>su:DAT</sub>	250			ns
Measurement System Characteristics	•					
Read delay time		t <sub>DLY</sub>	153	192	231	μs
Output current measurement range		$I_{RNG}$	0		26	А
Output current measurement resolution		I <sub>RES</sub>	62.5			mA
Output current measurement accuracy at 25C (with $I_{\text{OUT}, \text{CORR}}$ )	-40°C to +85°C	I <sub>ACC</sub>			±5	%
Output current measurement offset		I <sub>OFST</sub>			0.1	Α
VOUT measurement range		V <sub>OUT(rng)</sub>	0		5.5	V
VOUT measurement resolution		V <sub>OUT(res)</sub>		15.625		mV
VOUT measurement accuracy		V <sub>OUT, ACC</sub>	-15		5	%
VOUT measurement offset		V <sub>OUT(ofst)</sub>	-3		3	%
VIN measurement range		V <sub>IN(rng)</sub>	0		14.4	V
VIN measurement resolution		V <sub>IN(res)</sub>		32.5		mV
VIN measurement accuracy		V <sub>IN, ACC</sub>	-15		5	%
VIN measurement offset		V <sub>IN(ofst)</sub>	-5.5	-2	1.4	LSB



#### **Characteristic Curves**

The following figures provide typical characteristics for the 20A Digital MicroDLynx™ at 0.6V₀ and 25°C.




Figure 1. Converter Efficiency versus Output Current.




Figure 3. Typical output ripple and noise  $(C_0=2x47\mu F \text{ ceramic}, V_{IN}=12V, I_0=I_{0,max}).$ 




Figure 5. Typical Start-up Using On/Off Voltage ( $I_o = I_{o,max}$ ).




Figure 2. Derating Output Current versus Ambient Temperature and Airflow.




Figure 4. Transient Response to Dynamic Load Change from 50% to 100% at 12V $_{\rm in}$ , C $_{\rm out}$ = 1x47uF +11x330uF C $_{\rm Tune}$ =47nF, R $_{\rm Tune}$ =178 ohms




Figure 6. Typical Start-up Using Input Voltage  $(V_{IN} = 12V, I_o = I_{o,max})$ .



#### **Characteristic Curves** (continued)

The following figures provide typical characteristics for the 20A Digital MicroDLynx™ at 1.2V₀ and 25°C.




Figure 7. Converter Efficiency versus Output Current.




Figure 9. Typical output ripple and noise ( $C_0$ =2x47 $\mu$ F ceramic,  $V_{IN}$  = 12V,  $I_o$  =  $I_{o,max}$ ).




Figure 11. Typical Start-up Using On/Off Voltage ( $I_0 = I_{o,max}$ ).




Figure 8. Derating Output Current versus Ambient Temperature and Airflow.




Figure 10. Transient Response to Dynamic Load Change from 50% to 100% at 12Vin, Cout= 1x47uF +5x330uF CTune=10nF, R<sub>Tune</sub>=178 ohms




Figure 12. Typical Start-up Using Input Voltage



#### **Characteristic Curves** (continued)

The following figures provide typical characteristics for the 20A Digital MicroDLynx™ at 1.8V₀ and 25°C.




Figure 13 Converter Efficiency versus Output Current.




Figure 15. Typical output ripple and noise  $(C_0=2x47\mu F \text{ ceramic}, V_{IN}=12V, I_0=I_{o,max}).$ 




Figure 17. Typical Start-up Using On/Off Voltage (I<sub>o</sub> = I<sub>o,max</sub>).




Figure 14. Derating Output Current versus Ambient Temperature and Airflow.




Figure 16. Transient Response to Dynamic Load Change from 50% to 100% at  $12V_{in}$ ,  $C_{out}$ = 2x47uF + 3x330uF  $C_{Tune}$ =5600nF,  $R_{Tune}$ =220 ohms




Figure 18. Typical Start-up Using Input Voltage ( $V_{\text{IN}}$  = 12V,  $I_{\text{o}}$  =  $I_{\text{o,max}}$ ).



#### **Characteristic Curves** (continued)

The following figures provide typical characteristics for the 20A Digital MicroDLynx™ at 2.5V₀ and 25°C.




Figure 19 Converter Efficiency versus Output Current.




Figure 21. Typical output ripple and noise  $(C_0=2x47\mu F \text{ ceramic}, V_{IN}=12V, I_0=I_{o,max}).$ 




Figure 23. Typical Start-up Using On/Off Voltage (I<sub>o</sub> = I<sub>o,max</sub>).




Figure 20. Derating Output Current versus Ambient Temperature and Airflow.




Figure 22. Transient Response to Dynamic Load Change from 50% to 100% at 12 $V_{in}$ ,  $C_{out}$ = 2x47uF +2x330uF,  $C_{Tune}$ =3300pF &  $R_{Tune}$ =220 ohms




Figure 24. Typical Start-up Using Input Voltage  $(V_{\text{IN}}$  = 12V,  $I_{\text{o}}$  =  $I_{\text{o,max}}$ ).



#### **Characteristic Curves** (continued)

The following figures provide typical characteristics for the 20A Digital MicroDLynx™ at 3.3V₀ and 25°C.




Figure 25 Converter Efficiency versus Output Current.




Figure 27. Typical output ripple and noise ( $C_0=2x47\mu F$  ceramic,  $V_{IN}=12V$ ,  $I_o=I_{o,max}$ ).




Figure 29. Typical Start-up Using On/Off Voltage (Io = Io,max).




Figure 26. Derating Output Current versus Ambient




Figure 28 Transient Response to Dynamic Load Change from 50% to 100% at 12 $V_{in}$ ,  $C_{out}$ = 5x47uF +1x330uF,  $C_{Tune}$ =2200pF &  $R_{Tune}$ =220 ohms




Figure 30. Typical Start-up Using Input Voltage ( $V_{\text{IN}}$  = 12V,  $I_{\text{o}}$  =  $I_{\text{o,max}}$ ).



#### **Characteristic Curves** (continued)

The following figures provide typical characteristics for the 20A Digital MicroDLynx™ at 5V₀ and 25°C.




Figure 31. Converter Efficiency versus Output Current.




Figure 33. Typical output ripple and noise ( $C_0=2x47\mu F$  ceramic,  $V_{IN}=12V$ ,  $I_0=I_{o,max}$ ).




Figure 35. Typical Start-up Using On/Off Voltage ( $I_o = I_{o,max}$ ).




Figure 32. Derating Output Current versus Ambient Temperature and Airflow.




Figure 34. Transient Response to Dynamic Load Change from 50% to 100% at 12V $_{in}$ ,  $C_{out}$ = 8x47uF,  $C_{Tune}$ =1500pF &  $R_{Tune}$ =220 ohms




Figure 36. Typical Start-up Using Input Voltage  $(V_{IN} = 12V, I_0 = I_{0,max}).$ 

Rev. 2.10

UDT020\_DS



#### **Design Considerations**

#### Input Filtering

The 20A Digital MicroDLynx<sup>™</sup> module should be connected to a low ac-impedance source. A highly inductive source can affect the stability of the module. An input capacitance must be placed directly adjacent to the input pin of the module, to minimize input ripple voltage and ensure module stability.

To minimize input voltage ripple, ceramic capacitors are recommended at the input of the module. Figure 37 shows the input ripple voltage for various output voltages at 20A of load current with 2x22  $\mu$ F or 3x22  $\mu$ F ceramic capacitors and an input of 12V.




Figure 37. Input ripple voltage for various output voltages with 2x22  $\mu$ F or 3x22  $\mu$ F ceramic capacitors at the input (20A load). Input voltage is 12V.

#### **Output Filtering**

These modules are designed for low output ripple voltage and will meet the maximum output ripple specification with 0.1 µF ceramic and 2x47 µF ceramic capacitors at the output of the module. However, additional output filtering may be required by the system designer for a number of reasons. First, there may be a need to further reduce the output ripple and noise of the module. Second, the dynamic response characteristics may need to be customized to a particular load step change.

To reduce the output ripple and improve the dynamic response to a step load change, additional capacitance at the output can be used. Low ESR polymer and ceramic capacitors are recommended to improve the dynamic response of the module. Figure 38 provides output ripple information for different external capacitance values at various Vo and a full load current of 20A. For stable operation of the module, limit the capacitance to less than the

maximum output capacitance as specified in the electrical specification table. Optimal performance of the module can be achieved by using the Tunable Loop<sup>TM</sup> feature described later in this data sheet.




Figure 38. Output ripple voltage for various output voltages with external 2x47 µF, 4x47 µF or 6x47 µF ceramic capacitors at the output (20A load). Input voltage is 12V.

#### Safety Considerations

For safety agency approval the power module must be installed in compliance with the spacing and separation requirements of the end-use safety agency standards, i.e., UL ANSI/UL\* 62368-1 and CAN/CSA+ C22.2 No. 62368-1 Recognized, DIN VDE 0868-1/A11:2017 (EN62368-1:2014/A11:2017)

For the converter output to be considered meeting the Requirements of safety extra-low voltage (SELV) or ES1, the input must meet SELV/ES1 requirements. The power module has extra-low voltage (ELV) outputs when all inputs are ELV.

The UDT020A0X series were tested using an external Little fuse 456 series fast-acting fuse rated at 30 A, 100  $V_{dc}$  in the ungrounded input.



#### **Analog Feature Descriptions**

#### Remote On/Off

The module can be turned ON and OFF either by using the ON/OFF pin (Analog interface) or through the PMBus interface (Digital). The module can be configured in a number of ways through the PMBus interface to react to the two ON/OFF inputs:

- Module ON/OFF can be controlled only through the analog interface (digital interface ON/OFF commands are ignored)
- Module ON/OFF can be controlled only through the PMBus interface (analog interface is ignored)
- Module ON/OFF can be controlled by either the analog or digital interface

The default state of the module (as shipped from the factory) is to be controlled by the analog interface only. If the digital interface is to be enabled, or the module is to be controlled only through the digital interface, this change must be made through the PMBus. These changes can be made and written to non-volatile memory on the module so that it is remembered for subsequent use.

#### Analog On/Off

The 20A Digital MicroDLynx<sup>™</sup> power modules feature an On/Off pin for remote On/Off operation. Two On/Off logic options are available. In the Positive Logic On/Off option, (device code suffix "4" – see Ordering Information), the module turns ON during a logic High on the On/Off pin and turns OFF during a logic Low. With the Negative Logic On/Off option, (no device code suffix, see Ordering Information), the module turns OFF during logic High and ON during logic Low. The On/Off signal should be always referenced to ground. For either On/Off logic option, leaving the On/Off pin disconnected will turn the module ON when input voltage is present.

For positive logic modules, the circuit configuration for using the On/Off pin is shown in Figure 39. When the external transistor Q2 is in the OFF state, the internal transistor Q7 is turned ON, which turn Q3 OFF which keeps Q6 OFF and Q5 OFF. This allows the internal PWM #Enable signal to be pulled up by the internal 3.3V, thus turning the module ON. When transistor Q2 is turned ON, the On/Off pin is pulled low, which turns Q7 OFF which turns Q3, Q6 and Q5 ON and the internal PWM #Enable signal is pulled low and the module is OFF. A suggested value for  $R_{\text{pullup}}$  is  $20k\Omega$ .

For negative logic On/Off modules, the circuit configuration is shown in Fig. 40. The On/Off pin should be pulled high with an external pull-up resistor (suggested value for the 3V to 14V input range is 20Kohms). When transistor Q2 is in the OFF state, the On/Off pin is pulled high, transistor Q3 is turned ON. This turns Q6 ON, followed by Q5 turning ON which pulls the internal ENABLE low and the module is OFF. To turn the module ON, Q2 is turned ON pulling the On/Off pin low, turning transistor Q3 OFF, which keeps Q6 and Q5 OFF resulting in the PWM Enable pin going high.

#### Digital On/Off

Please see the Digital Feature Descriptions section.




Figure 39. Circuit configuration for using positive On/Off logic.




Figure 40. Circuit configuration for using negative On/Off logic.

#### Monotonic Start-up and Shutdown

The module has monotonic start-up and shutdown behavior for any combination of rated input voltage, output current and operating temperature range.

#### Startup into Pre-biased Output

The module can start into a prebiased output as long as the prebias voltage is 0.5V less than the set output voltage.



#### **Analog Feature Descriptions** (continued)

#### **Analog Output Voltage Programming**

The output voltage of the module is programmable to any voltage from 0.6dc to  $5.5 V_{dc}$  by connecting a resistor between the Trim and SIG\_GND pins of the module. Certain restrictions apply on the output voltage set point depending on the input voltage. These are shown in the Output Voltage vs. Input Voltage Set Point Area plot in Fig. 41. The Upper Limit curve shows that for output voltages lower than 1V, the input voltage must be lower than the maximum of 14.4V. The Lower Limit curve shows that for output voltages higher than 0.6V, the input voltage needs to be larger than the minimum of 3V.




Figure 41. Output Voltage vs. Input Voltage Set Point Area plot showing limits where the output voltage can be set for different input voltages.




Figure 42. Circuit configuration for programming output voltage using an external resistor.

**Caution** – Do not connect SIG\_GND to GND elsewhere in the layout

Without an external resistor between Trim and SIG\_GND pins, the output of the module will be  $0.6V_{dc}$ . To calculate the value of the trim resistor,  $R_{trim}$  for a desired output voltage, should be as per the following equation:

$$R_{trim-down} = \frac{12}{(V_o - 0.6)} k\Omega$$

 $R_{trim}$  is the external resistor in  $k\Omega$ 

Vo is the desired output voltage.

Table 1 provides  $R_{\text{trim}}$  values required for some common output voltages.

<b>V</b> <sub>O, set</sub> <b>(V)</b>	$R_{trim}$ (K $\Omega$ )
0.6	Open
0.9	40
1.0	30
1.2	20
1.5	13.33
1.8	10
2.5	6.316
3.3	4.444
5.0	2.727

Table 1

#### Digital Output Voltage Adjustment

Please see the Digital Feature Descriptions section.

#### Remote Sense

The power module has a Remote Sense feature to minimize the effects of distribution losses by regulating the voltage between the sense pins (VS+ and VS-). The voltage drop between the sense pins and the V<sub>OUT</sub> and GND pins of the module should not exceed 0.5V.

#### **Analog Voltage Margining**

Output voltage margining can be implemented in the module by connecting a resistor, R<sub>margin-up</sub>, from the Trim pin to the ground pin for margining-up the output voltage and by connecting a resistor, R<sub>margin-down</sub>, from the Trim pin to output pin for margining-down. Figure 43 shows the circuit configuration for output voltage margining. The POL Programming Tool, available at omnionpower.com under the Downloads section, also calculates the values of R<sub>margin-up</sub> and R<sub>margin-down</sub> for a specific output voltage and % margin. Please consult your local OmniOn technical representative for additional details.



#### **Analog Feature Descriptions** (continued)

#### **Analog Voltage Margining (continued)**




Figure 43. Circuit Configuration for margining Output voltage.

#### **Digital Output Voltage Margining**

Please see the Digital Feature Descriptions section.

#### **Output Voltage Sequencing**

The power module includes a sequencing feature, EZ-SEQUENCE that enables users to implement various types of output voltage sequencing in their applications. This is accomplished via an additional sequencing pin. When not using the sequencing feature, leave it unconnected.

The voltage applied to the SEQ pin should be scaled down by the same ratio as used to scale the output voltage down to the reference voltage of the module. This is accomplished by an external resistive divider connected across the sequencing voltage before it is fed to the SEQ pin as shown in Fig. 44. In addition, a small capacitor (suggested value 100pF) should be connected across the lower resistor R1.

For all DLynx modules, the minimum recommended delay between the ON/OFF signal and the sequencing signal is 10ms to ensure that the module output is ramped up according to the sequencing signal. This ensures that the module soft-start routine is completed before the sequencing signal is allowed to ramp up.




Figure 44. Circuit showing connection of the sequencing signal to the SEQ pin.

When the scaled down sequencing voltage is applied to the SEQ pin, the output voltage tracks this voltage until the output reaches the set-point voltage. The final value of the sequencing voltage must be set higher than the set-point voltage of the module. The output voltage follows the sequencing voltage on a one-to-one basis. By connecting multiple modules together, multiple modules can track their output voltages to the voltage applied on the SEQ pin.

To initiate simultaneous shutdown of the modules, the SEQ pin voltage is lowered in a controlled manner. The output voltage of the modules tracks the voltages below their set-point voltages on a one-to-one basis. A valid input voltage must be maintained until the tracking and output voltages reach ground potential.

Note that in all digital DLynx series of modules, the PMBus Output Undervoltage Fault will be tripped when sequencing is employed. This will be detected using the STATUS\_WORD and STATUS\_VOUT PMBus commands. In addition, the SMBALERT# signal will be asserted low as occurs for all faults and warnings. To avoid the module shutting down due to the Output Undervoltage Fault, the module must be set to continue operation without interruption as the response to this fault (see the description of the PMBus command VOUT\_UV\_FAULT\_RESPONSE for additional information).

#### **Overcurrent Protection**

To provide protection in a fault (output overload) condition, the unit is equipped with internal current-limiting circuitry and can endure current limiting continuously. At the point of current-limit inception, the unit enters hiccup mode. The unit operates normally once the output current is brought back into its specified range.



#### **Analog Feature Descriptions** (continued)

#### **Digital Adjustable Overcurrent Warning**

Please see the Digital Feature Descriptions section.

#### **Overtemperature Protection**

To provide protection in a fault condition, the unit is equipped with a thermal shutdown circuit. The unit will shut down if the over-temperature threshold of  $128^{\circ}\text{C} \sim 130^{\circ}\text{C}$  (typ) is exceeded at the thermal reference point T<sub>ref</sub> .Please refer to Electrical characteristic table, over-temperature section on page 5. Once the unit goes into thermal shutdown it will then wait to cool before attempting to restart.

#### Digital Temperature Status via PMBus

Please see the Digital Feature Descriptions section.

## Digitally Adjustable Output Over and Under Voltage Protection

Please see the Digital Feature Descriptions section.

#### Input Undervoltage Lockout

At input voltages below the input undervoltage lockout limit, the module operation is disabled. The module will begin to operate at an input voltage above the undervoltage lockout turn-on threshold.

#### Digitally Adjustable Input Undervoltage Lockout

Please see the Digital Feature Descriptions section.

#### Digitally Adjustable Power Good Thresholds

Please see the Digital Feature Descriptions section.

#### Synchronization

The module switching frequency can be synchronized to a signal with an external frequency within a specified range. Synchronization can be done by using the external signal applied to the SYNC pin of the module as shown in Fig. 45, with the converter being synchronized by the rising edge of the external signal. The Electrical Specifications table specifies the requirements of the external SYNC signal. If the SYNC pin is not used, the module should free run at the default switching frequency. If synchronization is not being used, connect the SYNC pin to GND.




Figure 45. External source connections to synchronize switching frequency of the module.

# Measuring Output Current, Output Voltage and Input Voltage

Please see the Digital Feature Descriptions section.

#### **Dual Layout**

Identical dimensions and pin layout of Analog and Digital MicroDLynx modules permit migration from one to the other without needing to change the layout. In both cases the trim resistor is connected between trim and signal ground. The output of the analog module cannot be trimmed down to 0.45V

#### **Power Good**

The module provides a Power Good (PGOOD) signal that is implemented with an open-drain output to indicate that the output voltage is within the regulation limits of the power module. The PGOOD signal will be de-asserted to a low state if any condition such as overtemperature, overcurrent or loss of regulation occurs that would result in the output voltage going  $\pm 10\%$  outside the setpoint value. The PGOOD terminal can be connected through a pullup resistor (suggested value  $100 \text{K}\Omega$ ) to a source of  $5\text{V}_{\text{DC}}$  or lower.

#### Tunable Loop™

The module has a feature that optimizes transient response of the module called Tunable Loop<sup>TM</sup>.

External capacitors are usually added to the output of the module for two reasons: to reduce output ripple and noise (see Figure 38) and to reduce output voltage deviations from the steady-state value in the presence of dynamic load current changes. Adding external capacitance however affects the voltage control loop of the module, typically causing the loop to slow down with sluggish response. Larger values of external capacitance could also cause the module to become unstable.



#### **Analog Feature Descriptions** (continued)

#### Tunable Loop™ (continued)

The Tunable Loop™ allows the user to externally adjust the voltage control loop to match the filter network connected to the output of the module. The Tunable Loop™ is implemented by connecting a series R-C between the VS+ and TRIM pins of the module, as shown in Fig. 46. This R-C allows the user to externally adjust the voltage loop feedback compensation of the module.




Figure. 46. Circuit diagram showing connection of  $R_{\text{TUNE}}$  and  $C_{\text{TUNE}}$  to tune the control loop of the module.

Recommended values of  $R_{TUNE}$  and  $C_{TUNE}$  for different output capacitor combinations are given in Tables 2 and 3. Table 3 shows the recommended values of  $R_{TUNE}$  and  $C_{TUNE}$  for different values of ceramic output capacitors up to 1000uF that might be needed for an application to meet output ripple and noise requirements. Selecting  $R_{TUNE}$  and  $C_{TUNE}$  according to Table 3 will ensure stable operation of the module.

In applications with tight output voltage limits in the presence of dynamic current loading, additional output capacitance will be required. Table 3 lists recommended values of  $R_{\text{TUNE}}$  and  $C_{\text{TUNE}}$  in order to meet 2% output voltage deviation limits for some common output voltages in the presence of a 10A to 20A step change (50% of full load), with an input voltage of 12V.

Please contact your OmniOn technical representative to obtain more details of this feature as well as for guidelines on how to select the right value of external R-C to tune the module for best transient performance and stable operation for other output capacitance values.

Co	2x47μF	4x47µF	6x47µF	10x47µF	20x47µF
R <sub>TUNE</sub>	330	330	270	220	180
C <sub>TUNE</sub>	47pF	560pF	1200pF	2200pF	4700pF

Table 2. General recommended values of of  $R_{\text{TUNE}}$  and  $C_{\text{TUNE}}$  for  $V_{\text{in}}$ =12V and various external ceramic capacitor combinations.

Vo	5V	3.3V	2.5V	1.8V	1.2V	0.6V
			2x47µF			
C0	07/705	+ 1x330	+ 2x330	+ 3x330	+	+ 11x330
Co	8x47µF	μF	μF	μF	5x330µF	μF
		Polymer	Polymer	Polymer	Polymer	Polymer
R <sub>TUNE</sub>	220	220	220	220	180	180
C <sub>TUNE</sub>	1500pF	2200pF	3300pF	5600pF	10nF	47nF
ΔV	100mV	64mV	49mV	36mV	24mV	12mV

Table 3. Recommended values of  $R_{TUNE}$  and  $C_{TUNE}$  to obtain transient deviation of 2% of  $V_{out}$  for a 10A step load with  $V_{in}$ =12V.

Note: The capacitors used in the Tunable Loop tables are 47  $\mu$ F/3 m $\Omega$  ESR ceramic and 330  $\mu$ F/12 m $\Omega$  ESR polymer capacitors.

#### **Digital Feature Descriptions**

#### **PMBus Interface Capability**

The 20A Digital MicroDLynx<sup>™</sup> power modules have a PMBus interface that supports both communication and control. The PMBus Power Management Protocol Specification can be obtained from <a href="www.pmbus.org">www.pmbus.org</a>. The modules support a subset of version 1.1 of the specification (see Table 6 for a list of the specific commands supported). Most module parameters can be programmed using PMBus and stored as defaults for later use.

All communication over the module PMBus interface must support the Packet Error Checking (PEC) scheme. The PMBus master must generate the correct PEC byte for all transactions, and check the PEC byte returned by the module.

The module also supports the SMBALERT# response protocol whereby the module can alert the bus master if it wants to talk. For more information on the SMBus alert response protocol, see the System Management Bus (SMBus) specification.


The module has non-volatile memory that is used to store configuration settings. Not all settings programmed into the device are automatically saved into this non-volatile memory, only those specifically identified as capable of being stored can be saved (see Table 6 for which command parameters can be saved to non-volatile storage).



#### **Digital Feature Descriptions** (continued)

#### **PMBus Data Format**

For commands that set thresholds, voltages or report such quantities, the module supports the "Linear" data format among the three data formats supported by PMBus. The Linear Data Format is a two byte value with an 11-bit, two's complement mantissa and a 5-bit, two's complement exponent. The format of the two data bytes is shown below:



The value is of the number is then given by Value = Mantissa  $x \, 2^{\text{Exponent}}$ 

#### **PMBus Addressing**

The power module can be addressed through the PMBus using a device address. The module has 64 possible addresses (0 to 63 in decimal) which can be set using resistors connected from the ADDRO and ADDR1 pins to GND. Note that some of these addresses (0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11 12, 40, 44, 45, 55 in decimal) are reserved according to the SMBus specifications and may not be useable. The address is set in the form of two octal (0 to 7) digits, with each pin setting one digit. The ADDR1 pin sets the high order digit and ADDRO sets the low order digit. The resistor values suggested for each digit are shown in Table 4 (1% tolerance resistors are recommended). Note that if either address resistor value is outside the range specified in Table 4, the module will respond to address 127.

Digit	Resistor Value ( $K\Omega$ )
0	10
1	15.4
2	23.7
3	36.5
4	54.9
5	84.5
6	130
7	200

Table 4

The user must know which I<sup>2</sup>C addresses are reserved in a system for special functions and set the address of the module to avoid interfering with other system operations. Both I00kHz and 400kHz bus speeds are supported by the module. Connection for the PMBus interface should follow the High Power DC specifications given in section 3.1.3 in the SMBus specification V2.0 for the 400kHz bus speed or the Low Power DC specifications in section 3.1.2. The complete SMBus specification is available from the SMBus web site, smbus.org.




Figure 47. Circuit showing connection of resistors used to set the PMBus address of the module.

#### PMBus Enabled On/Off

The module can also be turned on and off via the PMBus interface. The OPERATION command is used to actually turn the module on and off via the PMBus, while the ON\_OFF\_CONFIG command configures the combination of analog ON/OFF pin input and PMBus commands needed to turn the module on and off. Bit [7] in the OPERATION command data byte enables the module, with the following functions:

0: Output is disabled

1: Output is enabled

This module uses the lower five bits of the ON\_OFF\_CONFIG data byte to set various ON/OFF options as follows:

Bit Position	4	3	2	1	0
Access	r/w	r/w	r/w	r/w	r
Function	PU	CMD	CPR	POL	CPA
Default Value	1	0	1	Χ	1

PU: Sets the default to either operate any time input power is present or for the ON/OFF to be controlled by the analog ON/OFF input and the PMBus OPERATION command. This bit is used together with the CP, CMD and ON bits to determine startup.



#### **Digital Feature Descriptions** (continued)

#### PMBus Enabled On/Off (continued)

<b>Bit Value</b>	Action
0	Module powers up any time power is present regardless of state of the analog ON/OFF pin
1	Module does not power up until commanded by the analog ON/OFF pin and the OPERATION command as programmed in bits [2:0] of the ON_OFF_CONFIG register.

CMD: The CMD bit controls how the device responds to the OPERATION command.

<b>Bit Value</b>	Action
0	Module ignores the ON bit in the OPERATION command
1	Module responds to the ON bit in the OPERATION command

CPR: Sets the response of the analog ON/OFF pin. This bit is used together with the CMD, PU and ON bits to determine startup.

Bit Value	Action	
0	Module ignores the analog ON/OFF pin, i.e.ON/OFF is only controlled through the PMBUS via the OPERATION command	
1	Module requires the analog ON/OFF pin to be asserted to start the unit	

#### PMBus Adjustable Soft Start Rise Time

The soft start rise time can be adjusted in the module via PMBus. When setting this parameter, make sure that the charging current for output capacitors can be delivered by the module in addition to any load current to avoid nuisance tripping of the overcurrent protection circuitry during startup. The TON\_RISE command sets the rise time in ms, and allows choosing soft start times between 600µs and 9ms, with possible values listed in Table 5. Note that the exponent is fixed at -4 (decimal) and the upper two bits of the mantissa are also fixed at 0.

Rise Time	Exponent	Mantissa
600µs	11100	0000001010
900µs	11100	0000001110
1.2ms	11100	00000010011
1.8ms	11100	00000011101
2.7ms	11100	00000101011
4.2ms	11100	00001000011
6.0ms	11100	00001100000
9.0ms	11100	00010010000

Table 5

#### Output Voltage Adjustment Using the PMBus

The VOUT\_SCALE\_LOOP parameter is important for a number of PMBus commands related to output voltage trimming, margining, over/under voltage protection and the PGOOD thresholds. The output voltage of the module is set as the combination of the voltage divider formed by  $R_{\text{Trim}}$  and a  $20 k\Omega$  upper divider resistor inside the module, and the internal reference voltage of the module. The reference voltage  $V_{\text{REF}}$  is nominally set at 600mV, and the output regulation voltage is then given by

$$V_{OUT} = \frac{20000 + R_{Trim}}{R_{Trim}} \times V_{REF}$$

Hence the module output voltage is dependent on the value of  $R_{\text{Trim}}$  which is connected external to the module. The information on the output voltage divider ratio is conveyed to the module through the VOUT\_SCALE\_LOOP parameter which is calculated as follows:

$$VOUT\_SCALE\_LOOP = \frac{R_{Trim}}{20000 + R_{Trim}}$$

The VOUT\_SCALE\_LOOP parameter is specified using the "Linear" format and two bytes. The upper five bits [7:3] of the high byte are used to set the exponent which is fixed at –9 (decimal). The remaining three bits of the high byte [2:0] and the eight bits of the lower byte are used for the mantissa. The default value of the mantissa is 00100000000 corresponding to 256 (decimal), corresponding to a divider ratio of 0.5. The maximum value of the mantissa is 512 corresponding to a divider ratio of 1. Note that the resolution of the VOUT\_SCALE\_LOOP command is 0.2%.

When PMBus commands are used to trim or margin the output voltage, the value of VREF is what is changed inside the module, which in turn changes the regulated output voltage of the module.

The nominal output voltage of the module can be adjusted with a minimum step size of 0.4% over a ±25% range from nominal using the VOUT\_TRIM command over the PMBus.

The VOUT\_TRIM command is used to apply a fixed offset voltage to the output voltage command value using the "Linear" mode with the exponent fixed at -10 (decimal). The value of the offset voltage is given by

UDT020\_DS



#### **Digital Feature Descriptions** (continued)

# Output Voltage Adjustment Using the PMBus (continued)

V<sub>OUT(offset)</sub> = VOUT\_TRIM x 2<sup>-10</sup>

This offset voltage is added to the voltage set through the divider ratio and nominal VREF to produce the trimmed output voltage. The valid range in two's complement for this command is –4000h to 3fffh. The high order two bits of the high byte must both be either 0 or 1. If a value outside of the +/-25% adjustment range is given with this command, the module will set it's output voltage to the nominal value (as if VOUT\_TRIM had been set to 0), assert SMBALRT#, set the CML bit in STATUS\_BYTE and the invalid data bit in STATUS\_CML.

#### **Output Voltage Margining Using the PMBus**

The module can also have its output voltage margined via PMBus commands. The command VOUT\_MARGIN\_HIGH sets the margin high voltage, while the command VOUT\_MARGIN\_LOW sets the margin low voltage. Both the VOUT\_MARGIN\_HIGH and VOUT\_MARGIN\_LOW commands use the "Linear" mode with the exponent fixed at –10 (decimal). Two bytes are used for the mantissa with the upper bit [7] of the high byte fixed at 0. The actual margined output voltage is a combination of the VOUT\_MARGIN\_HIGH or VOUT\_MARGIN\_LOW and the VOUT\_TRIM values as shown below.

V<sub>OUT(MH)</sub> = (VOUT\_MARGIN\_HIGH + VOUT\_TRIM)x 2<sup>-10</sup>

 $V_{OUT(ML)} = (VOUT_MARGIN_LOW + VOUT_TRIM)x 2^{-10}$ 

Note that the sum of the margin and trim voltages cannot be outside the ±25% window around the nominal output voltage. The data associated with VOUT\_MARGIN\_HIGH and VOUT\_MARGIN\_LOW can be stored to non-volatile memory using the STORE\_DEFAULT\_ALL command.

The module is commanded to go to the margined high or low voltages using the OPERATION command. Bits [5:2] are used to enable margining as follows:

00XX: Margin Off

0101: Margin Low (Ignore Fault)

0110 : Margin Low (Act on Fault)

1001: Margin High (Ignore Fault)

1010: Margin High (Act on Fault)

#### **PMBus Adjustable Overcurrent Warning**

The module can provide an overcurrent warning via the PMBus. The threshold for the overcurrent warning can be set using the parameter IOUT\_OC\_WARN\_LIMIT. This command uses the "Linear" data format with a two byte data word where the upper five bits [7:3] of the high byte represent the exponent and the remaining three bits of the high byte [2:0] and the eight bits in the low byte represent the mantissa. The exponent is fixed at -1 (decimal). The upper five bits of the mantissa are fixed at 0 while the lower six bits are programmable. For production codes after April 2013, the value for IOUT\_OC\_WARN\_LIMIT will be fixed at 25A. For earlier production codes the actual value for IOUT\_OC\_WARN\_LIMIT will vary from module to module due to calibration during production testing. The resolution of this warning limit is 500mA. The value of the IOUT\_OC\_WARN\_LIMIT can be stored to non-volatile memory using the STORE\_DEFAULT\_ALL command.

#### Temperature Status via PMBus

The module can provide information related to temperature of the module through the STATUS\_TEMPERATURE command. The command returns information about whether the pre-set over temperature fault threshold and/or the warning threshold have been exceeded.

#### PMBus Adjustable Output Over and Under Voltage Protection

The module has output over and under voltage protection capability. The PMBus command VOUT\_OV\_FAULT\_LIMIT is used to set the output over voltage threshold from four possible values: 108%, 110%, 112% or 115% of the commanded output voltage. The command VOUT\_UV\_FAULT\_LIMIT sets the threshold that causes an output under voltage fault and can also be selected from four possible values: 92%, 90%, 88% or 85%. The default values are 112% and 88% of commanded output voltage. Both commands use two data bytes formatted as two's complement binary integers. The "Linear" mode is used with the exponent fixed to –10 (decimal) and the effective over or under voltage trip points given by:

 $V_{OUT(OV\_REQ)} = (VOUT\_OV\_FAULT\_LIMIT) \times 2^{-10}$ 

 $V_{OUT(UV\_REQ)} = (VOUT\_UV\_FAULT\_LIMIT)x 2^{-10}$ 



#### **Digital Feature Descriptions** (continued)

# PMBus Adjustable Output Over and Under Voltage Protection (continued)

Values within the supported range for over and undervoltage detection thresholds will be set to the nearest fixed percentage. Note that the correct value for VOUT\_SCALE\_LOOP must be set in the module for the correct over or under voltage trip points to be calculated.

In addition to adjustable output voltage protection, the 12A Digital Pico DLynx™ module can also be programmed for the response to the fault. The VOUT\_OV\_FAULT RESPONSE and VOUT\_UV\_FAULT\_RESPONSE commands specify the response to the fault. Both these commands use a single data byte with the possible options as shown below.

- 1. Continue operation without interruption (Bits [7:6] = 00, Bits [5:3] = xxx)
- Continue for four switching cycles and then shut down if the fault is still present, followed by no restart or continuous restart (Bits [7:6] = 01, Bits [5:3] = 000 means no restart, Bits [5:3] = 111 means continuous restart)
- 3. Immediate shut down followed by no restart or continuous restart (Bits [7:6] = 10, Bits [5:3] = 000 means no restart, Bits [5:3] = 111 means continuous restart).
- 4. Module output is disabled when the fault is present and the output is enabled when the fault no longer exists (Bits [7:6] = 11, Bits [5:3] = xxx).

Note that separate response choices are possible for output over voltage or under voltage faults.

#### PMBus Adjustable Input Undervoltage Lockout

The module allows adjustment of the input under voltage lockout and hysteresis. The command VIN\_ON allows setting the input voltage turn on threshold, while the VIN\_OFF command sets the input voltage turn off threshold. For the VIN\_ON command, possible values are 2.75V, and 3V to 14V in 0.5V steps. For the VIN\_OFF command, possible values are 2.5V to 14V in 0.5V steps. If other values are entered for either command, they will be mapped to the closest of the allowed values.

Both the VIN\_ON and VIN\_OFF commands use the "Linear" format with two data bytes. The upper five bits represent the exponent (fixed at -2) and the remaining 11 bits represent the mantissa. For the mantissa, the four most significant bits are fixed at 0.

#### **Power Good**

The module provides a Power Good (PGOOD) signal that is implemented with an open-drain output to indicate that the output voltage is within the regulation limits of the power module. The PGOOD signal will be de-asserted to a low state if any condition such as overtemperature, overcurrent or loss of regulation occurs that would result in the output voltage going outside the specified thresholds. The PGOOD thresholds are user selectable via the PMBus (the default values are as shown in the Feature Specifications Section). Each threshold is set up symmetrically above and below the nominal value. The POWER\_GOOD\_ON command sets the output voltage level above which PGOOD is asserted (lower threshold). For example, with a 1.2V nominal output voltage, the POWER\_GOOD\_ON threshold can set the lower threshold to 1.14 or 1.1V. Doing this will automatically set the upper thresholds to 1.26 or 1.3V.

The POWER\_GOOD\_OFF command sets the level below which the PGOOD command is de-asserted. This command also sets two thresholds symmetrically placed around the nominal output voltage. Normally, the POWER\_GOOD\_ON threshold is set higher than the POWER\_GOOD\_OFF threshold.

Both POWER\_GOOD\_ON and POWER\_GOOD\_OFF commands use the "Linear" format with the exponent fixed at –10 (decimal). The two thresholds are given by

 $V_{OUT(PGOOD\_ON)} = (POWER\_GOOD\_ON)x 2^{-10}$ 

V<sub>OUT(PGOOD OFF)</sub> = (POWER\_GOOD\_OFF)x 2<sup>-10</sup>

Both commands use two data bytes with bit [7] of the high byte fixed at 0, while the remaining bits are r/w and used to set the mantissa using two's complement representation. Both commands also use the The VOUT\_SCALE\_LOOP parameter so it must be set correctly. The default value of POWER\_GOOD\_ON is set at 1.1035V and that of the POWER\_GOOD\_OFF is set at 1.08V. The values associated with these commands can be stored in non-volatile memory using the STORE\_DEFAULT\_ALL command. PGOOD terminal can be connected through a pullup resistor (suggested value  $100 \text{K}\Omega$ ) to a source of  $5 \text{V}_{DC}$  or lower.



#### **Digital Feature Descriptions** (continued)

## Measurement of Output Current, Output Voltage and Input Voltage

The module is capable of measuring key module parameters such as output current and voltage and input voltage and providing this information through the PMBus interface. Roughly every 200µs, the module makes 16 measurements each of output current, voltage and input voltage. Average values of each of these measurements are then calculated and placed in the appropriate registers. These values in the registers can then be read using the PMBus interface.

#### Measuring Output Current Using the PMBus

The module measures current by using the inductor winding resistance as a current sense element. The inductor winding resistance is then the current gain factor used to scale the measured voltage into a current reading. This gain factor is the argument of the IOUT\_CAL\_GAIN command, and consists of two bytes in the linear data format. The exponent uses the upper five bits [7:3] of the high data byte in two-s complement format and is fixed at –15 (decimal). The remaining 11 bits in two's complement binary format represent the mantissa. During manufacture, each module is calibrated by measuring and storing the current gain factor into non-volatile storage.

The current measurement accuracy is also improved by each module being calibrated during manufacture with the offset in the current reading. The IOUT\_CAL\_OFFSET command is used to store and read the current offset. The argument for this command consists of two bytes composed of a 5-bit exponent (fixed at -4d) and a 11-bit mantissa. This command has a resolution of 62.5mA and a range of -4000mA to +3937.5mA.

The READ\_IOUT command provides module average output current information. This command only supports positive or current sourced from the module. If the converter is sinking current a reading of 0 is provided. The READ\_IOUT command returns two bytes of data in the linear data format. The exponent uses the upper five bits [7:3] of the high data byte in two-s complement format and is fixed at – 4 (decimal). The remaining 11 bits in two's complement binary format represent the mantissa with the 11th bit fixed at 0 since only positive numbers are considered valid.

Note that the current reading provided by the module is not corrected for temperature. The temperature corrected current reading for module temperature  $T_{\text{Module}}$  can be estimated using the following equation

$$I_{OUT,CORR} = \frac{I_{READ\_OUT}}{1+[(T_{IND} - 30) \times 0.00393]}$$

where  $I_{\text{OUT\_CORR}}$  is the temperature corrected value of the current measurement,  $I_{\text{READ\_OUT}}$  is the module current measurement value, TIND is the temperature of the inductor winding on the module. Since it may be difficult to measure  $T_{\text{IND}}$ , it may be approximated by an estimate of the module temperature.

#### Measuring Output Voltage Using the PMBus

The module can provide output voltage information using the READ\_VOUT command. The command returns two bytes of data all representing the mantissa while the exponent is fixed at -10 (decimal).

During manufacture of the module, offset and gain correction values are written into the non-volatile memory of the module. The command VOUT\_CAL\_OFFSET can be used to read and/or write the offset (two bytes consisting of a 16-bit mantissa in two's complement format) while the exponent is always fixed at -10 (decimal). The allowed range for this offset correction is -125 to 124mV. The command VOUT\_CAL\_GAIN can be used to read and/or write the gain correction - two bytes consisting of a five-bit exponent (fixed at -8) and a 11-bit mantissa. The range of this correction factor is -0.125 to +0.121, with a resolution of 0.004. The corrected output voltage reading is then given by:

 $V_{\text{OUT}}(\text{Final}) = [V_{\text{OUT}}(\text{Initial}) \times (1 + \text{VOUT\_CAL\_GAIN})] + \text{VOUT\_CAL\_OFFSET}$ 

#### Measuring Input Voltage Using the PMBus

The module can provide output voltage information using the READ\_VIN command. The command returns two bytes of data in the linear format. The upper five bits [7:3] of the high data form the two's complement representation of the exponent which is fixed at –5 (decimal). The remaining 11 bits are used for two's complement representation of the mantissa, with the 11th bit fixed at zero since only positive numbers are valid.

During module manufacture, offset and gain correction values are written into the non-volatile memory of the module. The command VIN\_CAL\_OFFSET can be used to read and/or write the offset - two bytes consisting of a fivebit exponent (fixed at -5) and all-bit mantissa in two's complement format. The allowed range for this offset correction is -2to 1.968V, and the resolution is 32mV. The command VIN\_CAL\_GAIN can be used to read and/or write the gain correction - two bytes consisting of a five-bit exponent (fixed at -8) and a 11-bit mantissa. The range of this correction factor is -0.125 to +0.121, with a resolution of 0.004. The corrected output voltage reading is then given by:



#### **Digital Feature Descriptions** (continued)

## Measuring Input Voltage Using the PMBus (continued)

 $V_{IN}(Final) = [V_{IN}(Initial) \times (1 + VIN_CAL_GAIN)] + VIN_CAL_OFFSET$ 

#### Reading the Status of the Module using the PMBus

The module supports a number of status information commands implemented in PMBus. However, not all features are supported in these commands. A 1 in the bit position indicates the fault that is flagged.

STATUS\_BYTE: Returns one byte of information with a summary of the most critical device faults.

Bit Position	Flag	Default Value
7	X	0
6	OFF	0
5	V <sub>o∪T</sub> Overvoltage	0
4	I <sub>OUT</sub> Overcurrent	0
3	V <sub>IN</sub> Undervoltage	0
2	Temperature	0
1	CML (Comm. Memory Fault)	0
0	None of the above	0

STATUS\_WORD: Returns two bytes of information with a summary of the module's fault/warning conditions.

Bit Position	Flag	Default Value
7	X	0
6	OFF	0
5	V <sub>out</sub> Overvoltage	0
4	I <sub>OUT</sub> Overcurrent	0
3	V <sub>IN</sub> Undervoltage	0
2	Temperature	0
1	CML (Comm. Memory Fault)	0
0	None of the above	0

**Low Byte** 

Bit Position	Flag	Default Value
7	V <sub>o∪T</sub> fault or warning	0
6	l <sub>ο∪T</sub> fault for warning	0
5	X	0
4	X	0
3	Power_GOOD# (is negated)	0
2	X	0
1	X	0
0	X	0

**High Byte** 

STATUS\_VOUT: Returns one byte of information relating to the status of the module's output voltage related faults.

Bit Position	Flag	Default Value
7	V <sub>o∪T</sub> OV Fault	0
6	X	0
5	X	0
4	V <sub>o∪T</sub> UV Fault	0
3	X	0
2	X	0
1	X	0
0	X	0

STATUS\_IOUT: Returns one byte of information relating to the status of the module's output voltage related faults.

Bit Position	Flag	Default Value
7	I <sub>o∪T</sub> OC Fault	0
6	X	0
5	I <sub>o∪T</sub> OC Warning	0
4	X	0
3	X	0
2	X	0
1	X	0
0	X	0

STATUS\_TEMPERATURE: Returns one byte of information relating to the status of the module's temperature related faults.

Bit Position	Flag	Default Value
7	OT Fault	0
6	OT Warning	0
5	X	0
4	X	0
3	X	0
2	X	0
1	X	0
0	X	0



#### **Digital Feature Descriptions** (continued)

# Measuring Input Voltage Using the PMBus (continued)

STATUS\_CML: Returns one byte of information relating to the status of the module's communication related faults.

Bit Position	Flag	Default Value
7	Invalid/Unsupported	0
	Command	
6	Invalid/Unsupported	0
	Command	
5	Packet Error Check Failed	0
4	X	0
3	X	0
2	X	0
1	Other Communication Fault	0
0	X	0

MFR\_VIN\_MIN: Returns minimum input voltage as two data bytes of information in Linear format (upper five bits are exponent – fixed at -2, and lower 11 bits are mantissa in two's complement format – fixed at 12)

MFR\_VOUT\_MIN: Returns minimum output voltage as two data bytes of information in Linear format (upper five bits are exponent – fixed at -10, and lower 11 bits are mantissa in two's complement format – fixed at 614)

MFR\_SPECIFIC\_00: Returns information related to the type of module. Bits [7:2] in the Low Byte indicate the module type (000010 corresponds to the UDT020 series of module). Bits 1:0 in the High Byte are used to indicate the manufacturer ID, with 00 reserved for OmniOn.

Bit Position	Flag	Default Value
7:2	Module Name	000010
1:0	Reserved	10

Low Byte

Bit Position	Flag	Default Value
7:0	Module Revision Number	None
1:0	Reserved	00

**High Byte** 



## **Summary of Supported PMBus Commands**

Please refer to the PMBus 1.1 specification for more details of these commands.

Hex Code	Command			Brie	f Descr	iption					Non-Volatile Memory Storage
		Turn Module o	n or o	ff. Also	used to	o marc	in the	outp	ut vol	tage	
		Format						•		<u> </u>	
		Bit Position	7	6	5 5	signed 4	3	<b>y</b> 2	1	0	
01	OPERATION	Access	r/w	r	r/w	r/w	r/w	r/w	r	r	
		Function	On	X	1/ 00	Marg		1/ ۷۷	X	X	
		Default Value	0	0	0	0	0	0	X	X	
		Configures the analog ON/OFF						binati	on of		
		Format			Uns	igned	Binar	V			
02	ON_OFF_CONFIG	Bit Position	7	6	5	4	3	2	1	0	YES
02	011_011_001110	Access	r	r	r	r/w	r/w	r/w	r/w	r	125
		Function	Χ	Χ	Χ	pu	cmd	cpr	pol	сра	
		Default Value	0	0	0	1	0	1	1	1	
03	CLEAR_FAULTS	Clear any fault SMBALERT# si								he	
		Used to contro current registe matches the va (EEPROM) on t	l writi r setti alue ir	ng to ng in n the c	the mod	dule via dule w	a PME hose o	Bus. Co	pies t and c	ode	
		Format		Jaare	Uns	igned	Binar	v			
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r/w	r/w	r/w	X	X	X	Х	X	
		Function	bit7	bit6	bit5	Χ	Χ	Χ	Χ	Χ	
10	Welte pootest	Default Value	0	0	0	X	X	X	X	Χ	\/50
10	WRITE_PROTECT	Bit 5: 0 – Enable 1 – Disable POPERATIO and ON_ Bit 6: 0 – Enable OPERATIO Bit 7: 0 – Enable 1 – Disable command (bit5 and I	es all von ON ON OFF OFF OFF OFF OFF OFF OFF OFF O	vrites CONF writes writes writes writes	except t IG (bit 6 as pern except f nds (bit5 as perr except f except f	the WF and b nitted i for the and b nitted for the	RITE_P it7 mu n bit5 WRITI it7 mu in bit5 WRITI	ROTE ust be or bit E_PRO ust be or bit E_PRO	CT, 0) 7 OTECT 0) t6 OTECT		YES
11	STORE_DEFAULT_ALL	Copies all curre volatile memor for the comma	ry (EEI	PROM	I) on the	in the modu	modi ile. Tal	ule int kes ab	o non out 50	1- 0ms	
12	RESTORE_DEFAULT_ALL	Restores all cui in the module	rrent r	egiste	er settin				rom v	alues'	
13	STORE_DEFAULT_CODE	Copies the cu command cod volatile memor Bit Position Access Function	urrent le ma	regis tches	ster set the valu I) on the <b>5</b> W	ting in	n the ne dat ile 3 W	mod ta byt <b>2</b> W			
14	RESTORE_DEFAULT_CODE	Restores the cu command cod value in the mo Bit Position Access Function	e mat odule <b>7</b> W	ches t	the valu colatile n <b>5</b> W	e in the nemor	e data y (EEF <b>3</b> W	byte PROM <b>2</b> W	from t		



Hex Code	Command			Brie	f Desc	ription	1				Non-Volatile Memory Storage
Code		The module ha	as MO	DF set	tolin	ear and	d Expo	nent	set to	-10.	Memory Storage
		These values c	annot	be ch	anged		o,,,p o				
		<b>Bit Position</b>	7	6	5	4	3	2	1	0	
20	VOUT_MODE	Access	r	r	r	r	r	r	r	r	
		Function		Mode			Ex	poner	nt		
		Default Value		0	0	1	0	1	1	0	
		Apply a fixed o		/oltage	to the	e set ou	ıtput v	oltag	е		
		command valu	Je	Lino	or twee	o's com	nlom	ont bi	inor.		
		Bit Position	7	6	ar, two	4	3	2	mary 1	0	
		Access	r/w	r	r/w	r/w	r/w	r/w	r/w	r/w	
22	VOUT_TRIM	Function	1/ **	'	1, **	High		1/ **	1/ ۷۷	1/ **	YES
22	VOOT_TRIM	Default Value	0	0	0	0	0	0	0	0	YES
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
		Function				Low E	<u> </u>				
		Default Value		0	0	0	0	0	0	0	
		Sets the target	: volta	ge for	margi	ning th	ne outp	out hi	gh		
		Format		Line	ar, two	o's com	plem	ent bi	inary		
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
25	VOUT MARGIN HIGH	Function	_	1	1	High	T			1	YES
25	VOOTEMAKOMEMON	Default Value		0	0	0	0	1	0	1	TES
		Bit Position	7	6 r/w	5 r/w	4 r/w	3 r/w	2	r/w	O r/w	
		Access Function	r/w	1/00	1/00	Low E		r/w	I/VV	I/VV	
		Default Value	0	1	0	0	) O	1	1	1 1	
		Sets the target						1 1	1 1	'	
			. voita								
		Format			_	's com	_	_	nary		
		Bit Position	7	6	5	4	3	2		0	
		Access	r	r/w	r/w	r/w High	r/w	r/w	r/w	r/w	
26	VOUT_MARGIN_LOW	Function	0			nign 0	Вусе 0	٦,	0	0	YES
		Default Value Bit Position	7	0 6	5	4	3	2	1	0	
1		Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
		Function	1, **	1, **	1, **	Low E	,	1/ **	1/ **	1/ **	
		Default Value	0	1	0	1	0	0	0	1	
		Sets the scaling								nack	1
		resistor divider	ratio	ie out	Jul VOI	raye –	equal	to the	reedi	uack	
		Format		Line	ar. two	o's com	plem	ent bi	inarv		
		Bit Position	7	6	5	4	3	2	1	0	
1		Access	r	r	r	r	r	r	r/w	r/w	
29	VOUT_SCALE_LOOP	Function		1	1	High	Byte	1	-		YES
	VOOT_SCALL_LOOP	Default Value	1	0	1	1	1	0	0	1	123
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
		Function		1	1	Low E	3yte	1		1	
		Default Value	0	0	0	0	0	0	0	0	]

Table 6 (continued)



Sets the value of input voltage at which the module turns on   Format	Hex Code	Command			Brie	f Desc	riptior	n				Non-Volatile Memory Storage
Sit Position   7   6   5   4   3   2   1   0     Access   r   r   r   r   r   r   r   r   r			Sets the value	of inp	ut volt	age at	which	the m	odule	turns	s on	
Sit Position   7   6   5   4   3   2   1   0     Access   r   r   r   r   r   r   r   r   r			Format		Line	ar two	's com	nleme	ant hi	narv		
Access				7						1 al y	0	
Function   Exponent   Mantissa   Default Value   1   1   1   1   0   0   0   0   0   0						<del>                                     </del>			<b>-</b>	r		
Default Value		,,,,,			E	xpone	ent		M	1antis	sa	\/50
Access   r   r/w   r/w	35	VIN_ON	Default Value	1	1	1	1	0	0	0	0	YES
Function			Bit Position	7	6	5	4		2	1	0	
Default Value   O   O   O   O   O   O   O   O   O				r	r/w	r/w	,		r/w	r/w	r/w	
Sets the value of input voltage at which the module turns off   Format					r			issa		ı		
Section   Format   Linear, two's complement binary			Default Value	0	0	0	0	1	0	1	1	
Bit Position   7   6   5   4   3   2   1   0     Access   r   r   r   r   r   r   r     Function   Exponent   Mantissa     Default Value   1   1   1   1   0   0   0   0     Bit Position   7   6   5   4   3   2   1   0     Access   r   r/w   r/w   r/w   r/w   r/w   r/w     Function   Mantissa     Default Value   0   0   0   0   1   0   1   0     Returns the value of the gain correction term used to correct the measured output current    Format   Linear, two's complement binary     Bit Position   7   6   5   4   3   2   1   0     Access   r   r   r   r   r   r   r   r   r			Sets the value	of inp	ut volt	age at	which	the m	odule	turns	s off	
Bit Position   7   6   5   4   3   2   1   0     Access   r   r   r   r   r   r   r     Function   Exponent   Mantissa     Default Value   1   1   1   1   0   0   0   0     Bit Position   7   6   5   4   3   2   1   0     Access   r   r/w   r/w   r/w   r/w   r/w   r/w     Function   Mantissa     Default Value   0   0   0   0   1   0   1   0     Returns the value of the gain correction term used to correct the measured output current    Format   Linear, two's complement binary     Bit Position   7   6   5   4   3   2   1   0     Access   r   r   r   r   r   r   r   r   r			Format		Line	ar two	's com	nlem	ent hi	narv		
Access   r   r   r   r   r   r   r   r   r				7						1	0	
Function   Exponent   Mantissa   Default Value   1   1   1   1   0   0   0   0   0   0							-	1		r	+	
Default Value	7.0	\"\\ 055			E	Expone	ent	I	N	1antis	sa	\/50
Access	36	VIN_OFF		1	1	1	1	0	0	0	0	YES
Function   Default Value   O   O   O   O   O   O   O   O   O			Bit Position	7	6	5	4	3	2	1	0	
Default Value			Access	r	r/w	r/w			r/w	r/w	r/w	
Returns the value of the gain correction term used to correct the measured output current							Mant	issa				
## The measured output current    Format			Default Value	0	0	0	0	1	0	1	0	
Bit Position   7   6   5   4   3   2   1   0     Access   r   r   r   r   r   r   r   r   r			the measured	lue of outpu	ut curre	ent					rect	
Access   r   r   r   r   r   r   r   r   r				7						nary	0	
Section   Exponent   Mantissa   YES						<del>                                     </del>				r		
Default Value	70	IOUT CAL CAIN		'						lantic	'	VEC
Bit Position   7   6   5   4   3   2   1   0     Access   r/w     Function   Mantissa     Default Value   V: Variable based on factory calibration      Returns the value of the offset correction term used to correct the measured output current	30	IOUT_CAL_GAIN		1	1	T .		1				YES
Function				7						1		
Returns the value of the offset correction term used to correct the measured output current    Format   Linear, two's complement binary			Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
Returns the value of the offset correction term used to correct the measured output current    Format   Linear, two's complement binary			Function			•	Mant	issa		1		
the measured output current    Format   Linear, two's complement binary			Default Value	\	/: Varia	ıble ba	sed on	factor	y calil	oratio	n	
Bit Position   7   6   5   4   3   2   1   0			the measured	lue of outpu	ut curre	ent					orrect	
Access   r   r   r   r   r   r   r   r   r					Line	ar, two				nary		
Tunction   Exponent   Mantissa					6	5	4	-		1	0	
Default Value				r	l r	r	r	r		<u>r</u>	r	
Bit Position 7 6 5 4 3 2 1 0  Access r r r/w r/w r/w r/w r/w r/w  Function Mantissa  Default Value 0 0 V 0 0 V  V 0 0 V	39	IOUT_CAL OFFSET		1	1	xpone						
Access r r r/w r/w r/w r/w r/w r/w  Function Mantissa  Default Value 0 0 V: Variable based on factory				-	•	I				1		
Function Mantissa  Profession V: Variable based on factory					-					r/\^/		
Default Value 0 V: Variable based on factory				•	<u>'</u>	1, VV	,		., • •	., ••	., ••	
Default Value 0 0 calibration			Default Value	0	0	V:	Variab	le bas		facto	ry	

Table 6 (continued)



Hex Code	Command			Brie	f Desc	riptior	n				Non-Volatile Memory Storage
		Sets the voltag is fixed at -10. S changed for di 112% or 115% of	Sugge fferer	sted va it outp	alue sh ut volt	nown fo	or 1.2Vc	. Sho	uld be	<u> </u>	
		Format	σαιρι			's com	npleme	ent bi	narv		
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
40	VOUT_OV_FAULT_LIMIT	Function		-	1 -	High	Byte			1 -	YES
		Default Value	0	0	0	Ō	0	1	0	1	
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
		Function				Low E	Byte		•		
		Default Value	0	1	1	0	0	0	0	0	
		Instructs the moutput overvol	nodule tage f	e on w ault	hat ac	tion to	take ir	resp	onse t	to a	
		Format			Un	signe	d Binar	У			
41	VOUT_OV_FAULT_RESPONS	Bit Position	7	6	5	4	3	2	1	0	YES
41	E	Access	r/w	r/w	r/w	r/w	r/w	r	r	r	YES
		Function	RSP [1]	RSP [0]	RS[2]	RS[1]	RS[0]	Х	Х	Х	
		Default Value	1	1	1	1	1	1	0	0	
		Sets the voltag Exponent is fix Should be cha 92%, 90%, 88% <b>Format</b>	ed a nged	at -10. S for diff % of ou	Sugges erent ( itput v	sted va output	lue sho voltag	own f e. Val	or 1.2V ues ca	o. an be	
		Bit Position	7	6	5	4	3	2	111 J	0	
		Access	r	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
44	VOUT_UV_FAULT_LIMIT	Function	•	.,	.,	High	<u> </u>	.,	.,	.,	YES
		Default Value	0	0	0	0	0	1	0	0	
		Bit Position	7	6	5	4	3	2	1	Ö	
		Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
		Function		-		Low E	Byte			1	
		Default Value	0	0	1	1	1	0	0	1	
		Instructs the moutput underv	nodule oltage	e on w e fault	hat ac	tion to	take ir	resp	onse t	to a	
		Format			Un	signed	d Binar	У			
45	VOUT_UV_FAULT_	Bit Position	7	6	5	4	3	2	1	0	YES
7-5	RESPONSE	Access	r/w	r/w	r/w	r/w	r/w	r	r	r	1
		Function	RSP [1]	RSP [0]	RS[2]	RS[1]	RS[0]	Х	Х	Х	
		Default Value	0	0	0	0	0	1	0	0	
		Sets the outpu changed)	t over				•				
		Format				's com			nary		
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r	r	R	
46	IOUT_OC_FAULT_LIMIT	Function		Е	xpone	nt			<u>lantis</u>	sa	
		Default Value									
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r	r	R	
		Function	0	0	7	Mant		7			
		Default Value	0	0	1	]	0	I	0	0	

Table 6 (continued)



## **Summary of Supported PMBus Commands** (continued)

Hex Code	Command			E	Brief I	Desc	ription	n					Non-Volatile Memory Storage
ooue		Sets the outp	ut ov	ercui	rrent	fault	level i	n A					
		Format			inear	. two	's com	nplei	ment	binar	V		
		Bit Position	7		6	5	4	3			C	)	
		Access	r		r	r	r	r	r	r	r		
4A	IOUT OC WARN LIMIT	Function			Ex	pone	nt	1		Mant	tissa		YES
44	IOUT_OC_WARN_LIMIT	Default Value	1 و		1	1	1	1	0	С	) C	)	YES
		Bit Position	7	(	6	5	4	3	2	1	С	)	
		Access	r		r	r/w	r/w	r/v	v r/v	v r/\	v r∕\	Ν	
		Function					Mant	issa					
		Default Value			0	1	1	0	_		C	)	
		Sets the outp asserted high	ut vo										
		Format		Li	near	, two	's com	nplei	ment	binar	У		
		Bit Position	7		6	5	4	3			С		
		Access	r	r/	w	r/w	r/w	r/v	v r/v	v r/\	v r∕\	Ν	
5E	POWER_GOOD_ON	Function					High	Byte	<u> </u>				YES
		Default Value			0	0	0	0		С			
		Bit Position	7		6	5	4	3			C		
		Access	r/w	v r/	/w	r/w	r/w	r/v		v r/\	<i>N</i>   r/\	Ν	
		Function			,	-	Low E	Byte					
		Default Value Sets the outp			1		0	I	0		C	)	
		asserted low	ut vo	itage	e ieve	ı at w	/nich ti	ne P	GOOL	) pin i	s ae-		
		Format		Li	inear	, two	's com	nplei	ment	binar	У		
		Bit Position	7		6	5	4	3			C		
		Access	r	r/	/w	r/w	r/w	r/v		v r/\	<i>N</i> r/\	$\sim$	
5F	POWER_GOOD_OFF	Function		•			High			•			YES
		Default Value			0	0	0	0		C			
		Bit Position	7		6	5	4	3			C		
		Access	r/v	v r/	/w	r/w	r/w	r/v		v r/\	<i>N</i> r/\	N	
		Function	2 0		,	0	Low I	Byte				_	
		Default Value Sets the rise t			Outr	_	oltago	_	_		C	)	
			iiiie (										
		Format Bit Position	7		lnear 6	, two	's com 4	1 <b>916</b> 1			<b>y</b>   C	`	
			r	-	r	r	r	r	r		<del></del>		
		Access Function	1			pone		<u> </u>		Mant		/ V	
61	OT_WARN_LIMIT	Default Value	1	1	1 [	1	0	0	0			`	YES
		Bit Position	7	-	6	5	4	3		_	, C		
		Access	r/w			r/w	r/w	r/v					
		Function	1,	,		.,	Mant		, .	, .			
		Default Value	9 0	(	0	1	0	1	0	1	1		
		Returns one b	yte c	of info	orma	tion \	with a	sum	mary	of the	mos	t	
		critical modul	e fau	ılts									
		Format				Uns	igned	Bina	ary				
		Bit Position	7	6	5	4	4	3	2	1	0		
78	STATUS_BYTE	Access	r	r	r		r	r	r	r	r		
		Flag	X	OFF	$V_{OUT_{\_}}$	O Iou	T_OC VI	N_UV	TEMP	CML	OTHE	ΞR	
		Default Value	0	0	0	(	0	0	0	0	0		
78	STATUS_BYTE	Bit Position Access Flag Default	r X	r OFF	r V <sub>OUT_</sub>	.º I <sub>ou</sub>	r r_oc Vii	3 r <sub>N_UV</sub> -	2 r TEMP	r CML	r OTHE	ΞR	

Table 6 (continued)



Returns two bytes of information with a summary of the module's fault/warning conditions	Hex Code	Command			Brief Do	escrip	tion				Non-Volatile Memory Storage
STATUS_NORD			Returns two b	ytes of ir	nformatio	n with	a sumr	nary of	the m	odule's	
Bit Position   7				Conditio		Uncia	nod Bin	25/			
Access				7 6				_	1	0	
Function								_			
Default Value	79	STATUS_WORD		V <sub>OUT</sub> I	Х		PGOOL				
Access			Default Value			0	0	0	0	0	
Flag			Bit Position	7 6	5	4	3	2	1	0	
Default Value			Access			•	-			•	
Returns one byte of information with the status of the module's output voltage related faults   Format						I <sub>OUT_OC</sub>		_			
STATUS_VOUT											
STATUS_VOUT			Returns one b output voltag	yte of inf e related	ormation faults	with	the stat	us of th	ie mod	lule's	
Access			Format			Unsig	ned Bir	nary			
Access	7Δ	STATUS VOUT	Bit Position	า 7	6	5	4	3 2	1	0	
Plady	,,,	317(103_001	Access	-	r			r r	r	r	
Returns one byte of information with the status of the module's output current related faults   Format				V		^	٧ '				
STATUS_IOUT   STATUS_TEMPERATURE   STATUS_CML   STATUS_						_			_	_	
STATUS_IOUT   Bit Position   7			Returns one b output curren	yte of inf it related	ormation faults	) with	the stat	us of th	ie mod	lule's	
Access   r   r   r   r   r   r   r   r   r			Format			Unsig	ned Bin	ary			
Access	7B	STATUS IOUT	Bit Position	า 7	6 5	5	4 3	2	1	0	
Tiling	/ / /	31A103_1001	Access	r			r r	r	r	r	
Returns one byte of information with the status of the module's temperature related faults    Format			Flag	I <sub>OUT_OC</sub>	^		X X	X	X	X	
To   STATUS_TEMPERATURE     STATUS_CML     STATUS_CML   STATUS_CML   STATUS_CML     STATUS_CML   STATUS_CML     STATUS_CML   STATUS_			Default Valu	ie 0	0 (	)	0 0	0	0	0	
STATUS_TEMPERATURE     Bit Position   7			Returns one b temperature i	yte of inf related fa	ormation ults	with	the stat	us of th	e mod	lule's	
Access			Format		U	nsign	ed Bina	ry			
Access	70	CTATUS TEMPEDATURE	Bit Position	7	6		5 4	3 2	2 1	0	
Default	///	STATUS_TEMPERATURE									
Returns one byte of information with the status of the module's communication related faults    Format			- 3	OT_FAILT	OT_ WA	RN :	X X	XX	X	X	
TE STATUS_CML Communication related faults    Format				0	0	(	0 0	0 0	0	0	
7E         STATUS_CML         Bit Position         7         6         5         4         3         2         1         0           Access         r<						with	the stat	us of th	ie mod	lule's	
TE STATUS_CML Access r r r r r r r r r r r r r r r r r r			Format			Jnsigr	ned Bina	ary			
Flag Invalid Invalid PEC X X X Other Comm X Fault Default 0 0 0 0 0 0 0 0 0			Bit Position	7	6	5	4	3 2	1	0	
Flag Invalid Invalid PEC X X X Other Comm X Default 0 0 0 0 0 0 0 0	7F	STATUS CMI	Access	r	r	r	r	r r			
Default 0 0 0 0 0 0	, _	37.1.33_31112	Flag				X	x x	Com	m X	
				0	0	0	0	0 0			

Table 6 (continued)



## **Summary of Supported PMBus Commands** (continued)

Hex Code	Command			Brie	f Desc	ription	1				Non-Volatile Memory Storage
Code		Returns the va	lue of	the in	put vo	ltage a	pplied	to the	e mod	lule	Memory Storage
		Format				o's com					
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r	r	r	
00	DEAD MAI	Function		Е	xpone	ent	1	M	1antiss	sa	
88	READ_VIN	Default Value	1	1	0	1	1	0	0	0	
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r	r	r	
		Function				Mant	issa			•	
		Default Value	0	0	0	0	0	0	0	0	
		Returns the va	lue of	f the ou	utput v	oltage/	of the	mod	ule		
		Format		Linea	ar, two	's com	plem	ent bi	nary		
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r	r	r	
0.0		Function			•	Mant	issa				
8B	READ_VOUT	Default Value	0	0	0	0	0	0	0	0	
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r	r	r	
		Function		T		Mant	issa	1		1	
		Default Value	0	0	0	0	0	0	0	0	
		Returns the va	lue of	f the ou	utput c	urrent	of the	mod	ule		
		Format		Linea	ar, two	o's com	plem	ent bi	nary		
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r	r	r	
8C	READ_IOUT	Function		E	xpone	ent		M	1antiss	sa	
00	READ_IOUT	Default Value	1	1	1	0	0	0	0	0	
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r	r	r	
		Function	0			Mant	1	1 0	1 0		
		Default Value	0	0	0	0	0	0	0	0	
		Returns one by PMBus Spec. 1.	/te in 1 (rea	dicatin d only)	g the r	module	e is cor	npliar	nt to		
		Format			_U.n	signe	d Bina	rv			
98	PMBUS_REVISION	Bit Position	7	6	5	4	3	2	1	0	YES
		Access	r	r	r	r	r	r	r	r	
		Default Value	0	0	0	1	0	0	0	1	
		Returns the mi	inim	ım innı	ut volt	200 th	o mod	ulo ic i	sposifi	iod to	1
		operate at (rea	d onl	im inpi v)	ut voit	age the	e moai	uie is s	speciii	ied to	
		Format		<i>,</i>	or +14/6	o's com	nlom	ant bi	now.		
			7			4	_	2	nary	0	
		Bit Position Access	7 r	6 r	5 r	r	3 r	r	l r	O r	
AO	MED VINLAGAL	Function	<u>'</u>		xpone		_ '		1 I 1antiss		VEC
AU	MFR_VIN_MIN	Default Value	1	l 1	1	1	0	0	0	0	YES
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r	r	r	
		Function			1	Mant	issa	1		1	
		Default Value	0	0	0	0	1	1	0	0	
L				•	*	*	*	•	•		1

Table 6 (continued)



Hex Code	Command			Brie	f Desc	riptior	1				Non-Volatile Memory Storage
		Returns the m module (read o	inimu only)	ım out	put vo	ltage p	ossible	e from	n the		
		Format		Line	ar, two	o's com	pleme	ent bi	nary		
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r	r	r	
A4	MFR_VOUT_MIN	Function		E	xpone	ent		V	1antis	sa	YES
		Default Value	0	0	0	0	0	0	1	0	
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r	r	r	
		Function				Mant	issa				
		Default Value	0	1	1	0	0	1	1	0	
		Returns modu	le nar	me info	ormatio	on (rea	d only)				
		Format			Un	signed	Bina	ry			
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r	r	r	
D0	MED CDECIFIC OF	Function		•		Reser	ved				\/50
D0	MFR_SPECIFIC_00	Default Value	0	0	0	0	0	0	0	0	YES
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r	r	r	
		Function		1	Module	e Name	<del>.</del>		Reser	ved	
		Default Value	0	0	0	0	1	0	1	0	
		Applies an offs calibrate out o output voltage	ffset e	errors i	n mod	ule me	asurer	ments			
		Format		Line	ar, two	o's com	pleme	ent bi	nary		
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r/w	r	r	r	r	r	r	r	
D4	VOUT_CAL_OFFSET	Function		•		Mant	issa	ı	.1	•	YES
		Default Value	V	0	0	0	0	0	0	0	
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r/w	r/w	r/w	r/w	r/w	r/w	r/w	
		Function				Mant	issa				
		Default Value	V	V	V	V	V	V	V	V	
		Applies a gain to calibrate ou output voltage	t gain	veen -	in mo 0.125 a	dule m nd 0.12	neasur 1)	emen	ts of tl	esults he	
		Format				o's com	_		nary	-	
		Bit Position	7	6	5	4	3	2		0	
D5	VOUT_CAL_GAIN	Access	r	r	r	r	r	r/w	r 1antiss	r	YES
	VOOT_CAL_GAIN	Function	1	1	xpone		Ι ο			sa V	I LJ
		Default Value	7	1 6	5	0 4	3	2	0	0	
		Bit Position	r		1				1	_	
		Access Function	- 1	r	r	r/w Mant	r/w issa	r/w	r/w	r/w	
		Default Value	V	V	V	V	V	V	V	V	
		Delault value	٧	L V	_ v	_ v	_ v	L V	_ v		

Table 6 (continued)



Hex Code	Command					riptior					Non-Volatile Memory Storage
		Applies an offs to calibrate out input voltage (l	et cor coffse betwe	rection et error een -2\	n to the s in m / and -	e READ odule r +1.968V	)_VIN ( measu )	comm reme	nand r nts of	esults the	
		Format		Linea	ar, two	's com	plemo	ent bi	nary		
		Bit Position	7	6	5	4	3	2	1	0	
D.6		Access	r	r	r	r	r	r	r/w	r	
D6	VIN_CAL_OFFSET	Function		Е	xpone	ent		M	1antis	sa	YES
		Default Value	1	1	0	1	V	0	0	V	
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r/w	r/w	r/w	r/w	r/w	r/w	
		Function				Mant	issa				
		Default Value	0	0	V	V	V	V	V	V	
		Applies a gain calibrate out gave voltage (betwee	ain er	rors in .125 an	modu d 0.121	ıle mea	surem	ients (	of the	ults to input	
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r	r/w	r	r	
D7	VIN_CAL_GAIN	Function		E	xpone	ent			lantis	sa	YES
		Default Value	1	1	0	1	V	0	0	V	
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r/w	r/w	r/w	r/w	r/w	r/w	
		Function		•	•	Mant	issa		•	•	
		Default Value	0	0	0	V	V	V	V	V	
					•	•		•	•	•	

Table 6 (continued)



#### Thermal Considerations

Power modules operate in a variety of thermal environments; however, sufficient cooling should always be provided to help ensure reliable operation.

Considerations include ambient temperature, airflow, module power dissipation, and the need for increased reliability. A reduction in the operating temperature of the module will result in an increase in reliability. The thermal data presented here is based on physical measurements taken in a wind tunnel. The test set-up is shown in Figure 48. The preferred airflow direction for the module is in Figure 49.




Figure 48. Thermal Test Setup.

The thermal reference points, Tref used in the specifications are also shown in Figure 49. For reliable operation the temperatures at these points should not exceed 120°C. The output power of the module should not exceed the rated power of the module  $(V_{o,set} \times I_{o,max})$ .

Please refer to the Application Note "Thermal Characterization Process For Open-Frame Board- Mounted Power Modules" for a detailed discussion of thermal aspects including maximum device temperatures.




Figure 49. Preferred airflow direction and location of hotspot of the module ( $T_{\rm ref}$ ).



#### **Shock and Vibration**

The ruggedized (-D version) of the modules are designed to withstand elevated levels of shock and vibration to be able to operate in harsh environments. The ruggedized modules have been successfully tested to the following conditions:

#### Non operating random vibration:

Random vibration tests conducted at 25C, 10 to 2000Hz, for 30 minutes each level, starting from 30Grms (Z axis) and up to 50Grms (Z axis). The units were then subjected to two more tests of 50Grms at 30 minutes each for a total of 90 minutes.

#### Operating shock to 40G per Mil Std. 810G, Method 516.4 Procedure I:

The modules were tested in opposing directions along each of three orthogonal axes, with waveform and amplitude of the shock impulse characteristics as follows:

All shocks were half sine pulses, 11 milliseconds (ms) in duration in all 3 axes.

Units were tested to the Functional Shock Test of MIL-STD-810, Method 516.4, Procedure I - Figure 516.4-4. A shock magnitude of 40G was utilized. The operational units were subjected to three shocks in each direction along three axes for a total of eighteen shocks.

#### Operating vibration per Mil Std 810G, Method 514.5 Procedure I:

The ruggedized (-D version) modules are designed and tested to vibration levels as outlined in MIL-STD-810G, Method 514.5, and Procedure 1, using the Power Spectral Density (PSD) profiles as shown in Table 7 and Table 8 for all axes. Full compliance with performance specifications was required during the performance test. No damage was allowed to the module and full compliance to performance specifications was required when the endurance environment was removed. The module was tested per MIL-STD-810, Method 514.5, Procedure I, for functional (performance) and endurance random vibration using the performance and endurance levels shown in Table 7 and Table 8 for all axes. The performance test has been split, with one half accomplished before the endurance test and one half after the endurance test (in each axis). The duration of the performance test was at least 16 minutes total per axis and at least 120 minutes total per axis for the endurance test. The endurance test period was 2 hours minimum per axis.

Frequency (Hz)	PSD Level	Frequency (Hz)	PSD Level	Frequency (Hz)	PSD Level (G2/Hz)
10	1.14E-03	170	2.54E-03	690	1.03E-03
30	5.96E-03	230	3.70E-03	800	7.29E-03
40	9.53E-04	290	7.99E-04	890	1.00E-03
50	2.08E-03	340	1.12E-02	1070	2.67E-03
90	2.08E-03	370	1.12E-02	1240	1.08E-03
110	7.05E-04	430	8.84E-04	1550	2.54E-03
130	5.00E-03	490	1.54E-03	1780	2.88E-03
140	8.20E-04	560	5.62E-04	2000	5.62E-04

**Table 7: Performance Vibration Qualification - All Axes** 

Frequency (Hz)	PSD Level(G2/Hz)	Frequency (Hz)	PSD Level (G2/Hz)	Frequency (Hz)	PSD Level (G2/Hz)
10	0.00803	170	0.01795	690	0.00727
30	0.04216	230	0.02616	800	0.05155
40	0.00674	290	0.00565	890	0.00709
50	0.01468	340	0.07901	1070	0.01887
90	0.01468	370	0.07901	1240	0.00764
110	0.00498	430	0.00625	1550	0.01795
130	0.03536	490	0.01086	1780	0.02035
140	0.0058	560	0.00398	2000	0.00398

**Table 8: Endurance Vibration Qualification - All Axes** 




#### **Example Application Circuit**

#### Requirements:

 $V_{in}$ : 12V  $V_{out}$ : 1.8V

 $I_{out}$ : 15A max., worst case load transient is from 10A to 15A  $\Delta V_{out}$ : 1.5% of  $V_{out}$  (27mV) for worst case load transient

 $V_{in, ripple}$  1.5% of  $V_{in}$  (180m $V_{p-p}$ )



CII Decoupling cap - 1x0.047µF/16V ceramic capacitor (e.g. Murata LLL185R71C473MA01)

CI2 3x22µF/16V ceramic capacitor (e.g. Murata GRM32ER61C226KE20)

CI3 470µF/16V bulk electrolytic

CO1 Decoupling cap - 1x0.047µF/16V ceramic capacitor (e.g. Murata LLL185R71C473MA01)

CO2 N.A.

CO3  $3 \times 330 \mu F/6.3 \text{V}$  Polymer (e.g. Sanyo Poscap)

C<sub>Tune</sub> 4700pF ceramic capacitor (can be 1206, 0805 or 0603 size) R<sub>Tune</sub> 330 ohms SMT resistor (can be 1206, 0805 or 0603 size)

 $R_{Trim}$  10k $\Omega$  SMT resistor (can be 1206, 0805 or 0603 size, recommended tolerance of 0.1%)


Note: The DATA, CLK and SMBALRT pins do not have any pull-up resistors inside the module. Typically, the SMBus master controller will have the pull-up resistors as well as provide the driving source for these signals.



#### **Mechanical Outline**

Dimensions are in millimeters and (inches).

Tolerances: x.x mm  $\pm$ 0.5 mm (x.xx in $\pm$ 0.02 in.) [Unless otherwise indicated] x.xx mm  $\pm$  0.25 mm (x.xxx in  $\pm$  0.010 in.)



PIN	<b>FUNCTION</b>	PIN	<b>FUNCTION</b>
1	ON/OFF	10	SYNC <sup>1</sup>
2	$V_{IN}$	11	CLK
3	SEQ	12	DATA
4	GND	13	SMBALERT#
5	TRIM	14	SIG_GND
6	VOUT	15	ADDR1
7	VS+	16	ADDR0
8	VS-		
9	PG		

<sup>&</sup>lt;sup>1</sup> If unused, connect to Ground.




### **Recommended Pad Layout**

Dimensions are in millimeters and (inches).

Tolerances: x.x mm ±0.5 mm (x.xx in±0.02 in.) [Unless otherwise indicated]

x.xx mm ± 0.25 mm (x.xxx in ± 0.010 in.)



RECOMMENDED FOOTPRINT -THROUGH THE BOARD-

PIN	<b>FUNCTION</b>	PIN	<b>FUNCTION</b>
1	ON/OFF	10	SYNC <sup>2</sup>
2	V <sub>IN</sub>	11	CLK
3	SEQ	12	DATA
4	GND	13	SMBALERT#
5	TRIM	14	SIG_GND
6	VOUT	15	ADDR1
7	VS+	16	ADDR0
8	VS-		
9	PG		


 $<sup>^{2}</sup>$  If unused, connect to Ground.




### **Packaging Details**

The 12V Digital MicroDLynx<sup>™</sup> 20A modules are supplied in tape & reel as standard. Modules are shipped in quantities of 200 modules per reel.

All Dimensions are in millimeters and (in inches).





#### **Reel Dimensions:**

Outside Dimensions: 330.2 mm (13.00)
Inside Dimensions: 177.8 mm (7.00")
Tape Width: 44.00 mm (1.732")

DETAIL A

Rev. 2.10



#### **Surface Mount Information**

#### Pick and Place

The 20A Digital MicroDLynx™ modules use an open frame construction and are designed for a fully automated assembly process. The modules are fitted with a label designed to provide a large surface area for pick and place operations. The label meets all the requirements for surface mount processing, as well as safety standards, and is able to withstand reflow temperatures of up to 300°C. The label also carries product information such as product code, serial number and the location of manufacture.

#### **Nozzle Recommendations**

The module weight has been kept to a minimum by using open frame construction. Variables such as nozzle size, tip style, vacuum pressure and placement speed should be considered to optimize this process. The minimum recommended inside nozzle diameter for reliable operation is 3mm. The maximum nozzle outer diameter, which will safely fit within the allowable component spacing, is 7 mm.

#### Bottom Side / First Side Assembly

Only the -D version of this module can be placed at the bottom side of the customer board. No additional glue or adhesive is required to hold the module during the top side reflow process. Serial numbers with date codes starting from 19xx21xxxxxx (19 – year, 21 - week) are suitable for bottom side placement.

#### **Lead Free Soldering**

The modules are lead-free (Pb-free) and RoHS compliant and fully compatible in a Pb-free soldering process. Failure to observe the instructions below may result in the failure of or cause damage to the modules and can adversely affect long-term reliability.

#### **Pb-free Reflow Profile**

Power Systems will comply with J-STD-020 Rev. C (Moisture/Reflow Sensitivity Classification for Nonhermetic Solid State Surface Mount Devices) for both Pb-free solder profiles and MSL classification procedures. This standard provides a recommended forced-air-convection reflow profile based on the volume and thickness of the package (table 4-2). The suggested Pb-free solder paste is Sn/Ag/Cu (SAC). For questions regarding Land grid array(LGA) soldering, solder volume; please contact OmniOn for special manufacturing process instructions. The recommended linear reflow profile using Sn/Ag/Cu solder is shown in Fig. 50. Soldering outside of the recommended profile requires testing to verify results and performance.

#### MSL Rating

The 20A Digital MicroDLynx<sup>TM</sup> modules have a MSL rating of 2a.

#### Storage and Handling

The recommended storage environment and handling procedures for moisture-sensitive surface mount packages is detailed in J-STD-033 Rev. A (Handling, Packing, Shipping and Use of Moisture/ Reflow Sensitive Surface Mount Devices). Moisture barrier bags (MBB) with desiccant are required for MSL ratings of 2 or greater. These sealed packages should not be broken until time of use. Once the original package is broken, the floor life of the product at conditions of  $\leq$  30°C and 60% relative humidity varies according to the MSL rating (see J-STD-033A). The shelf life for dry packed SMT packages will be a minimum of 12 months from the bag seal date, when stored at the following conditions: < 40°C, < 90% relative humidity.




Figure 50. Recommended linear reflow profile using Sn/Ag/Cu

#### Post Solder Cleaning and Drying Considerations

Post solder cleaning is usually the final circuit-board assembly process prior to electrical board testing. The result of inadequate cleaning and drying can affect both the reliability of a power module and the testability of the finished circuit-board assembly. For guidance on appropriate soldering, cleaning and drying procedures, refer to Board Mounted Power Modules: Soldering and Cleaning Application Note (ANO4-001).



#### **Ordering Information**

Please contact your OmniOn Sales Representative for pricing, availability and optional features.

Device Code	Input Voltage Range	Output Voltage	Output Current	On/OffLogic	Sequencing	Ordering codes
UDT020A0X3-SRZ	3-14.4V <sub>dc</sub>	0.45 – 5.5V <sub>dc</sub>	20A	Negative	Yes	CC109159728
UDT020A0X3- SRDZ	3-14.4V <sub>dc</sub>	0.45 – 5.5V <sub>dc</sub>	20A	Negative	Yes	CC109168745
UDT020A0X43- SRZ	3-14.4V <sub>dc</sub>	0.45 – 5.5V <sub>dc</sub>	20A	Positive	Yes	CC109159736

**Table 9. Device Codes** 

<sup>-</sup>Z refers to RoHS compliant parts

Package Identifier	Family	Sequencing Option	Output current	Output voltage	On/Off logic	Remote Sense		Options	ROHS Compliance
U	D	Т	020A0	Х		3	-SR	-D	Z
P=Pico U=Micro M=Mega G=Giga	D= Dlynx Digital V= DLynx	T=with EZ Sequence X=without sequencing	20A	X = Programma ble output	4 = positive No entry = negative	3 = Remote Sense	S = Surface Mount R = Tape &	D = 105°C operating ambient, 40G operating shockas per MIL Std. 810G,	Z = ROHS

Table 10. Coding scheme

#### **Accessories**

150036482 (I2C\_USB\_ISO\_TRANSLAT) - OmniOn Isolated I2C to USB Dongle with connecting cables CC109164430 (DIGITAL\_POL\_EVAL\_KIT) - OmniOn Isolated I2C to USB Dongle, Cables, PJT020 eval board, quick guide

OmniOn Power Electronics Inc.'s digital non-isolated DC-DC products may be covered by one or more of the following patents licensed from Bel Power Solutions, Inc.: US20040246754, US2004090219A1, US2004093533A1, US2004123164A1, US2004123167A1, US2004178780A1, US2004179382A1, US20050200344, US20050223252, US2005289373A1, US20060061214, US2006015616A1, US20060174145, US20070226526, US20070234095, US20070240000, US20080052551, US20080072080, US20080186006, US6741099, US6788036, US6936999, US6949916, US7000125, US7049798, US7068021, US7080265, US7249267, US7266709, US7315156, US7372682, US7373527, US7394445, US7456617, US7459892, US7493504, US7526660.

Outside the US Bel Power Solutions, Inc. licensed technology is protected by patents: AU3287379AA, AU3287437AA, AU3290643AA, AU3291357AA, CN10371856C, CN1045261OC, CN10458656C, CN10459360C, CN10465848C, CN11069332A, CN11124619A, CN11346682A, CN1685299A, CN1685459A, CN1685582A, CN1685583A, CN1698023A, CN1802619A, EP1561156A1, EP1561268A2, EP1576710A1, EP1576711A1, EP1604254A4, EP1604264A4, EP1714369A2, EP1745536A4, EP1769382A4, EP1899789A2, EP1984801A2, W004044718A1, W004045042A3, W004045042C1, W004062061 A1, W004062062A1, W004070780A3, W004084390A3, W004084391A3, W005079227A3, W005081771A3, W006019569A3, W02007001584A/3, W02007094935A3

#### **Contact Us**

For more information, call us at 1-877-546-3243 (US) 1-972-244-9288 (Int'l)



## **Change History (excludes grammar & clarifications)**

Revision	Date	Description of the change		
2.9	03/23/2022	Updated ROHS		
2.10	12/14/2023	Updated as per OmniOn template		

© 2023 OmniOn Power Inc. All rights reserved.



#### **OmniOn Power Inc.**

601 Shiloh Rd. Plano, TX USA

#### omnionpower.com

We reserve the right to make technical changes or modify the contents of this document without prior notice. OmniOn Power does not accept any responsibility for errors or lack of information in this document and makes no warranty with respect to and assumes no liability as a result of any use of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of OmniOn Power. This document does not convey license to any patent or any intellectual property right. Copyright© 2023 OmniOn Power Inc. All rights reserved.